

# EMISSION CONTROL SYSTEMS

|  | Page  |
|--|-------|
| SYSTEM PURPOSE.....                                      | EC-2  |
| COMPONENT LAYOUT AND SCHEMATIC<br>DRAWING .....          | EC-3  |
| POSITIVE CRANKCASE VENTILATION (PCV)<br>SYSTEM .....     | EC-4  |
| FUEL EVAPORATIVE EMISSION CONTROL<br>(EVAP) SYSTEM ..... | EC-5  |
| DASH POT (DP) SYSTEM.....                                | EC-7  |
| EXHAUST GAS RECIRCULATION (EGR)<br>SYSTEM .....          | EC-10 |
| THREE-WAY CATALYST (TWC) SYSTEM .....                    | EC-15 |


**NOTE: TROUBLESHOOTING**  
See page EM-2

**SYSTEM PURPOSE**


| System                            | Abbreviation | Purpose  |
|-----------------------------------|--------------|--|
| Positive crankcase ventilation    | PCV          | Reduces blow-by gas (HC)   |
| Fuel evaporative emission control | EVAP         | Reduces evaporative HC   |
| Dash pot                          | DP           | Reduces HC and CO  |
| Exhaust gas recirculation         | EGR          | Reduces NOx  |
| Three-way catalyst                | TWC          | Reduces HC, CO and NOx   |
| Electronic fuel injection*        | EFI          | Regulates all engine conditions for reduction of exhaust emissions |

Remarks \*For inspection and repair of the EFI system, refer to EFI section.


## COMPONENT LAYOUT AND SCHEMATIC DRAWING




E CD908



# POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM



To reduce HC emission, crankcase blow-by gas (HC) is routed through two metering orifices to the intake manifold for combustion in the cylinders



## INSPECTION OF PCV HOSES AND CONNECTIONS

### 1. VISUALLY INSPECT HOSES, CONNECTIONS AND GASKETS


Check for cracks, leaks or damage.



### 2. CLEAN TWO ORIFICES

Clean off any gum deposits in the orifices with solvent and blow out with compressed air.


## FUEL EVAPORATIVE EMISSION CONTROL (EVAP) SYSTEM



EC0005


To reduce HC emission, evaporated fuel from the fuel tank is routed through the charcoal canister to the intake manifold for combustion in the cylinders


| Coolant Temp.         | BVS    | Throttle Valve Opening      | Canister Check Valve |        |        | Check Valve in Cap | Evaporated Fuel (HC)                             |
|-----------------------|--------|-----------------------------|----------------------|--------|--------|--------------------|--|
|                       |        |                             | (1)                  | (2)    | (3)    |                    |  |
| Below 35°C (95°F)     | CLOSED | —                           | —                    | —      | —      | —                  | HC from tank is absorbed in the canister.        |
| Above 54°C (129°F)    | OPEN   | Positioned below purge port | CLOSED               | —      | —      | —                  |  |
|                       |        | Positioned above purge port | OPEN                 | —      | —      | —                  | HC from canister is led into air intake chamber. |
| High pressure in tank | —      | —                           | —                    | OPEN   | CLOSED | CLOSED             | HC from tank is absorbed in the canister.        |
| High vacuum in tank   | —      | —                           | —                    | CLOSED | OPEN   | OPEN               | (Air is led into the fuel tank)                  |



## INSPECTION OF FUEL VAPOR LINES, FUEL TANK AND FILLER CAP


- 1. VISUALLY INSPECT LINES AND CONNECTIONS**  
Look for loose connections, sharp bends or damage.
- 2. VISUALLY INSPECT FUEL TANK**  
Look for deformation, cracks or fuel leakage.
- 3. VISUALLY INSPECT FUEL FILLER CAP**  
Check condition of gasket and cap.  
If necessary, repair or replace the cap.






## INSPECTION OF CHARCOAL CANISTER

1. REMOVE CHARCOAL CANISTER
2. VISUALLY INSPECT CHARCOAL CANISTER CASE  
Look for cracks or damage.



3. CHECK FOR CLOGGED FILTER AND STUCK CHECK VALVE
  - (a) Using low pressure compressed air, blow into the tank pipe and check that the air flows without resistance from the other pipes.
  - (b) Blow into the purge pipe and check that the air does not flow from the other pipes.
 If a problem is found replace the charcoal canister.




## 4. CLEAN CANISTER FILTER

Clean the filter by blowing 3 kg/cm<sup>2</sup> (43 psi, 294 kPa) compressed air into the tank pipe, while holding the other upper canister pipe closed.

### NOTE:

- Do not attempt to wash the canister.
- No activated carbon should come out.


## 5. INSTALL CHARCOAL CANISTER



## INSPECTION OF BVS


### CHECK BVS BY BLOWING AIR INTO PIPE

- (a) Drain the coolant from the radiator into a suitable container.
- (b) Remove the BVS from the water outlet.
- (c) Cool the BVS to below 35°C (95°F) with cool water.
- (d) Blow air into a pipe and check that the BVS is closed.
- (e) Heat the BVS to above 54°C (129°F) with hot water.
- (f) Blow air into a pipe and check that the BVS is open.
- (g) Apply liquid sealer to the threads of the BVS and install.
- (h) Fill the radiator with coolant.






## DASH POT (DP) SYSTEM




EC1214

### Normal Driving



EC1215

### Deceleration




EC1216

To reduce HC and CO emissions, when decelerating the dash pot opens the throttle valve slightly more than at idle. This causes the air-fuel mixture to burn completely.

| Condition      | Diaphragm                                   | VTV    | Throttle Valve   |
|----------------|---|--------|--|
| Idling         | Pushed in by return force of throttle valve | CLOSED | Idle speed position                                    |
| Normal driving | Pushed out by diaphragm spring              | OPEN   | High speed position                                    |
| Deceleration   | Pushed in by return force of throttle valve | CLOSED | Slightly opens and then slowly closes to idle position |


## INSPECTION OF DP SYSTEM

1. WARM UP ENGINE
2. CHECK IDLE SPEED




### 3. CHECK DP SETTING SPEED

- (a) Maintain engine speed at 3,000 rpm.
- (b) Pinch the vacuum hose between DP and VTV.



- (c) Release the throttle valve.
  - (d) Check that the DP is set.
- DP setting speed: 2,000 rpm**




If not at specified speed, adjust with the DP adjusting bolt



### 4. CHECK OPERATION OF VTV

- (a) Set the DP speed in the same procedure as above; (b) to (c).
- (b) Release the pinched hose and check that the engine returns to idle speed in about 1 second.






## INSPECTION OF VTV

### 1. CHECK AND CLEAN FILTER ON VTV


- Check the filter for contamination or damage.
- Using compressed air, clean the filter.




### 2. CHECK VTV BY BLOWING AIR INTO EACH SIDE

- Check that air flows without resistance from B to A.
- Check that air flows with difficulty from A to B.


## EXHAUST GAS RECIRCULATION (EGR) SYSTEM




(1)



(2)



(3)



To reduce NO<sub>x</sub> emission, part of the exhaust gases are recirculated through the EGR valve to the intake manifold to lower the maximum combustion temperature.

| Coolant Temp.      | VSV   | Throttle Valve Opening Angle           | Pressure in the EGR Valve Pressure Chamber |   | EGR Vacuum Modulator         | EGR Valve | Exhaust Gas             |
|--------------------|-------|--|--|---|------------------------------|-----------|-------------------------|
| Below 57°C (135°F) | OPEN  | —                                      | —  |   | —                            | CLOSED    | Not recirculated        |
| Above 63°C (145°F) | CLOSE | Positioned below EGR port              | —  |   | —                            | CLOSED    | Not recirculated        |
|                    |       | Positioned between EGR port and R port | (1) LOW                                    | *Pressure constantly alternating between low and high | OPENS passage to atmosphere  | CLOSED    | Not recirculated        |
|                    |       |  | (2) HIGH                                   |   | CLOSES passage to atmosphere | OPEN      | Recirculated            |
|                    |       | Positioned above R port                | (3) HIGH                                   | **  | CLOSES passage to atmosphere | OPEN      | Recirculated (increase) |

Remarks:


\*Pressure increases

Modulator closes

EGR valve

Pressure


Exhaust gas



## INSPECTION OF EGR VALVE


### 1. CHECK AND CLEAN FILTER IN EGR VACUUM MODULATOR

- Check the filter for contamination or damage.
- Using compressed air, clean the filter.



### 2. PREPARATION

Disconnect the vacuum hose from the EGR valve and, using a three way union, connect a vacuum gauge to it.




### 3. CHECK SEATING OF EGR VALVE

Start the engine and check that the engine starts and runs smoothly at idle.


### 4. CHECK VSV WITH COLD ENGINE

- The coolant temperature should be below 57°C (135°F).
- Check that the vacuum gauge indicates zero at 2,500 rpm.




### 5. CHECK VSV AND EGR VACUUM MODULATOR WITH WARM ENGINE

- Warm up the engine.
- Check that the vacuum gauge indicates about 70 mmHg (2.76 in.Hg, 9.3 kPa) at 2,500 rpm.
- Check that the vacuum gauge indicates zero at idle.




- Disconnect the vacuum hose from R port of the EGR vacuum modulator and connect R port directly to the intake manifold with another hose.
- Check that the vacuum gauge indicates high vacuum at 2,500 rpm.



## 6. CHECK EGR VALVE

- Apply vacuum directly to the EGR valve with the engine idling.
- Check that the engine runs rough or dies.
- Reconnect the vacuum hoses to the proper location.


**IF NO PROBLEM IS FOUND WITH THIS INSPECTION, THE SYSTEM IS OKAY; OTHERWISE INSPECT EACH PART**




## INSPECTION OF EGR VACUUM MODULATOR

### CHECK EGR VACUUM MODULATOR OPERATION

- Disconnect the vacuum hoses from ports P, Q and R of the EGR vacuum modulator.
- Block ports P and R with your finger.
- Blow air into port Q. Check that the air passes through to the air filter side freely.




- Start the engine and maintain engine speed at 2,500 rpm.
  - Repeat the above test. Check that there is a strong resistance to air flow.
  - Disconnect the vacuum hoses to the proper location.
- If a problem is found, replace the EGR vacuum modulator.




## INSPECTION OF VSV

### 1. CHECK VACUUM CIRCUIT CONTINUITY IN THE VSV BY BLOWING AIR INTO PIPE

- Connect the VSV terminals to the battery terminals as illustrated.
- Blow air into a pipe and check that the VSV is open.




- Disconnect the battery.
  - Blow air into a pipe and check that the VSV is closed.
- If a problem is found, replace the VSV.

**2. CHECK FOR SHORT CIRCUIT**

Using an ohmmeter, check that there is no continuity between the terminals and the VSV body.

If there is continuity, replace the VSV.

**3. CHECK FOR OPEN CIRCUIT**

Using an ohmmeter, measure the resistance between terminals.

**Specified resistance: 38 – 44  $\Omega$  at 20°C (68°F)**

If the resistance is not within specification, replace VSV.

**INSPECTION OF EGR VALVE****1. REMOVE EGR VALVE**


Check the valve for sticking and heavy carbon deposits. If a problem is found, replace it.

**2. INSTALL EGR VALVE WITH NEW GASKET****INSPECTION OF WATER TEMP. SENSOR**

(See page FI-73)



## THREE-WAY CATALYST (TWC) SYSTEM



To reduce HC, CO and  $\text{NO}_x$  emissions, they are oxidized, reduced and converted to nitrogen ( $\text{N}_2$ ), carbon dioxide ( $\text{CO}_2$ ) and water ( $\text{H}_2\text{O}$ ) by the catalyst.

| Exhaust port              |   | TWC                     |   | Exhaust Gas   |
|---------------------------|---|-------------------------|---|---|
| HC, CO, AND $\text{NO}_x$ | → | OXIDATION AND REDUCTION | → | $\text{CO}_2$<br>$\text{H}_2\text{O}$<br>$\text{N}_2$ |


### INSPECTION OF EXHAUST PIPE ASSEMBLY

1. CHECK CONNECTIONS FOR LOOSENESS OR DAMAGE
2. CHECK CLAMPS FOR WEAKNESS, CRACKS OR DAMAGE


### INSPECTION OF CATALYTIC CONVERTER

#### CHECK FOR DENTS OR DAMAGE

If any part of protector is damaged or dented to the extent that it contacts the catalyst, repair or replace.








## INSPECTION OF HEAT INSULATOR

1. CHECK HEAT INSULATOR FOR DAMAGE
2. CHECK FOR ADEQUATE CLEARANCE BETWEEN CATALYTIC CONVERTER AND HEAT INSULATOR



## REPLACEMENT OF CATALYTIC CONVERTER

### 1. REMOVE CONVERTER

- (a) Jack up the vehicle.
- (b) Check that the converter is cool.
- (c) Remove the bolts at the front and rear of the converter.
- (d) Remove the converter and gaskets.

### 2. INSTALL CONVERTER

- (a) Place new gaskets on the converter front and rear pipes, and connect the converter to the exhaust pipes.
- (b) Tighten the bolts.

**Torque: Catalyst — Exhaust pipe**  
**440 kg-cm (32 ft-lb, 43 N·m)**

- (c) Reinstall the bracket bolts and tighten them.