


# BODY ELECTRICAL SYSTEM

	Page
GENERAL INFORMATION .....	BE-2
LOCATION OF SWITCHES AND RELAYS .....	BE-7
IGNITION SWITCH .....	BE-11
LIGHTING .....	BE-12
HEADLIGHT CLEANER .....	BE-21
WIPERS AND WASHERS .....	BE-22
INSTRUMENTS AND SENDER GAUGES .....	BE-27
REAR WINDOW DEFOGGER .....	BE-61
HEATER .....	BE-63
POWER WINDOW .....	BE-65
DOOR LOCK CONTROL SYSTEM .....	BE-67
SUN ROOF .....	BE-69
CRUISE CONTROL SYSTEM .....	BE-70
REMOTE CONTROL MIRROR .....	BE-85
MIRROR HEATER .....	BE-86
THEFT DETERRENT SYSTEM .....	BE-87
RADIO, STEREO TAPE PLAYER AND ANTENNA .....	BE-101
CLOCK .....	BE-111
TRIP COMPUTER .....	BE-113

Example:



8E0831

## GENERAL INFORMATION

### WIRING COLOR CODE

Wire colors are indicated by an alphabetical code.

B = Black	L = Light Blue	R = Red
BR = Brown	LG = Light Green	V = Violet
G = Green	O = Orange	W = White
GR = Gray	P = Pink	Y = Yellow

The first letter indicates the basic wire color and second letter indicates the color of the stripe.

### CONNECTOR

#### 1. PIN NUMBER OF FEMALE CONNECTOR

Numbered in order from upper left to lower right.

#### 2. PIN NUMBER OF MALE CONNECTOR

Numbered in order from upper right to lower left.




8E0832

#### 3. DISTINCTION OF MALE AND FEMALE CONNECTOR


Male and female connectors are distinguished by shape and their internal pins.

(a) All connectors are shown from the open end, and lock is on top.



8E0833

(b) To pull apart the connectors, pull on the connector itself, not the wires.




IN0001


### REPLACEMENT OF COMBINATION SWITCH

REMOVE TERMINALS FROM CONNECTOR






- (b) Pry up the locking lugs with the screwdriver and pull the terminal out from the rear.



### INSTALL TERMINALS TO CONNECTOR


- (a) Push in the terminal until it is securely locked in the connector lug.  
 (b) Pull on the wire to confirm that it is securely locked.



### RESET CIRCUIT BREAKER

#### 1. REMOVE CIRCUIT BREAKER

- (a) Remove the kick panel.  
 (b) Remove the circuit breaker.



#### 2. RESET CIRCUIT BREAKER

- (a) Insert the needle into the reset hole and push it.  
 (b) Using an ohmmeter, check that there is continuity between both terminals of the circuit breaker.

If there is no continuity, replace the circuit breaker.



#### 3. INSTALL CIRCUIT BREAKER

- (a) Install the circuit breaker.

**NOTE:** If a circuit breaker continues to cut out, a short circuit is indicated. Have the system checked by a qualified technician.


## REPLACEMENT OF FUSES

Install new fuses with correct amperage ratings.

### CAUTION:

1. Turn off all electrical components and the ignition switch before replacing a fuse. Do not exceed fuse amp rating.
2. Always use a fuse puller for removing and inserting a fuse. Remove and insert straight in and out without twisting. Twisting could force open the terminals too much, resulting in a bad connection.

If a fuse continues to blow, the circuit is probably shorted. Have the system checked by a qualified technician.



## Precautions

### TAKE CARE WHEN INSPECTING HEADLIGHT CIRCUIT

**WARNING:** With the headlight switch OFF, disconnect the pink fusible link before beginning work.


## VOLTAGE CHECK

- (a) Establish conditions in which voltage is present at the check point.

Example:



- Ⓐ – Ignition S/W on
- Ⓑ – Ignition S/W and S/W 1 on
- Ⓒ – Ignition S/W, S/W 1 and Relay on (S/W 2 off)

- (b) Using a voltmeter, connect the negative lead to a good ground point or negative battery terminal, and the positive lead to the connector or component terminal. This check can be done with a test lamp instead of a voltmeter.



## CONTINUITY AND RESISTANCE CHECK


- (a) Disconnect the battery terminal or wire so there is no voltage between the check points.
- (b) Contact the two leads of an ohmmeter to each of the check points.




If the circuit has diodes, reverse the two leads and check again.

When contacting the negative lead to the diode positive side and the positive lead to the negative side, there should be continuity.

When contacting the two leads in reverse, there should be no continuity.



- (c) Use a volt/ohmmeter with high impedance ( $10\text{ k}\Omega/\text{V}$  minimum) for troubleshooting of the electrical circuit.



## FINDING A SHORT CIRCUIT



- Remove the blown fuse and disconnect all loads from the fuse.
- Connect a test lamp in place of the fuse.
- Establish conditions in which the test lamp comes on.

Example:


- Ignition S/W on
  - Ignition S/W and S/W 1 on
  - Ignition S/W, S/W 1 and Relay on (Connect Relay) and S/W 2 off (or Disconnect S/W 2)
- Disconnect and reconnect the connectors while watching the test lamp. The short lies between the connector where the lamp stays lit and the connector where the lamp goes out.
- Find the exact location of the short by lightly shorting the problem wire along the body.

## LOCATION OF SWITCHES AND RELAYS


### ENGINE COMPARTMENT SWITCHES AND RELAYS




## INSTRUMENT PANEL SWITCHES AND RELAYS



## PASSENGER COMPARTMENT SWITCHES AND RELAYS



**PASSENGER AND LUGGAGE COMPARTMENT  
SWITCHES AND RELAYS**



H-6-2

## IGNITION SWITCH

### INSPECTION OF IGNITION SWITCH

#### INSPECT SWITCH CONTINUITY

Inspect the switch continuity between terminals.



Terminal		1	3	6	4	2	5
Switch position	LOCK						
	ACC	○—○					
	ON	○—○—○					
	START	○—○—○—○					
Warning	Normal						
	Push					○—○	

If continuity is not as specified, replace the switch.

## LIGHTING

### Troubleshooting

Problem	Possible cause	Remedy	Page
Only one light does not light (all exterior)	Light bulb burned out Socket, wire or ground faulty	Replace bulb Repair as necessary	
No headlights light	Fusible link blown Headlight control relay faulty Light control switch faulty Wiring or ground faulty	Replace fusible link Check relay Check switch Repair as necessary	BE- BE-
High beam headlights or headlight flasher do not operate	Light control switch faulty Wiring faulty	Check switch Repair as necessary	BE-
Tail, parking and license light do not light	TAIL fuse blown Fusible link blown Taillight control relay faulty Light control switch faulty Wiring or ground faulty	Replace fuse and check for short Replace fusible link Check relay Check switch Repair as necessary	BE- BE- BE-
Stop lights do not light	STOP fuse blown Stop light switch faulty Wiring or ground faulty	Replace fuse and check for short Adjust or replace switch Repair as necessary	BE-
Stop lights stay on	Stop light switch faulty	Adjust or replace switch	
Instrument lights do not light (taillights light)	Light control rheostat faulty Wiring or ground faulty	Check rheostat Repair as necessary	BE- 1
Turn signal does not flash on one side	Turn signal switch faulty Wiring or ground faulty	Check switch Repair as necessary	BE-
Turn signals do not operate	TURN fuse blown Turn signal flasher faulty Turn signal/hazard switch faulty Wiring or ground faulty	Replace fuse and check for short Check flasher Check switch Repair as necessary	BE- BE- BE-
Hazard warning lights do not operate	HAZ-HORN fuse blown Turn signal flasher faulty Turn signal/hazard switch faulty Wiring or ground faulty	Replace fuse and check for short Check flasher Check switch Repair as necessary	BE- BE- BE-

BE0111  
G-5-2

## Light Control Switch and Headlight Dimmer Switch

### INSPECTION OF LIGHT CONTROL SWITCH AND HEADLIGHT DIMMER SWITCH

INSPECT CONTINUITY OF LIGHT CONTROL SWITCH AND HEADLIGHT DIMMER SWITCH

Light control switch

Switch position \ Terminal (Wire color)	10 EL (W)	11 T (Y)	4 H (R)	26 U (LG-B)
OFF				
UP	○			○
TAIL	○	○		○
HEAD	○	○	○	

Headlight dimmer switch


Switch position \ Terminal (Wire color)	13 Ed (W-B)	6 HL (R-G)	5 Hu (R-Y)	12 Hf (R-W)
Flash	○		○	○
Low Beam	○	○		
High Beam	○		○	

If continuity is not as specified, replace the switch.

### REPLACEMENT OF LIGHT CONTROL SWITCH AND HEADLIGHT DIMMER SWITCH


REPLACE LIGHT CONTROL SWITCH AND HEADLIGHT DIMMER SWITCH

- Remove the terminals from the connector.  
(See page BE-2)
- Remove the light control switch.
- Remove the headlight dimmer switch.
- Install the headlight dimmer switch.
- Insert the spring into the lever and install the lever with the pin and E-ring.




BE0091






- (f) Place the ball on the spring, position the lever at and install the plate.



- (g) Insure that the switch operates smoothly.  
(h) Connect the terminals to the connector.  
(See pages BE-3 and 13)



## Light Control Relays (Headlight and Taillight)

### INSPECTION OF LIGHT CONTROL RELAY

#### 1. INSPECT RELAY CONTINUITY


- (a) Check that there is continuity between terminal 1 and 2.  
(b) Check that there is no continuity between terminal 1 and 3.

If continuity is not as specified, replace the relay.

#### 2. INSPECT RELAY OPERATION

- (a) Apply battery voltage across terminals 1 and 2.  
(b) Check that there is continuity between terminal 1 and 3.

If operation is not as specified, replace the relay.





## Light Retractor Relay

### INSPECTION OF LIGHT RETRACTOR RELAY

#### 1. INSPECT RELAY CONTINUITY

- (a) Check that there is continuity between terminal 1 and 2.






## 2. INSPECT RELAY OPERATION

- Connect the positive (+) lead from the battery to terminal 3. Connect the negative (–) lead to terminals 1 and 2.
- Check the continuity between terminals 3 and 5 and terminals 3 and 6.

If operation is not as specified, replace the relay.





## Light Retractor Control Relay

### INSPECTION OF LIGHT RETRACTOR CONTROL RELAY

#### INSPECT RELAY OPERATION

- Connect the positive (+) lead from the battery to terminal 5. Connect the negative (–) lead to terminal 1.
- Connect the negative (–) lead from the battery to terminal 3. After disconnecting the connection between terminal 3 and battery, check the continuity for 6 – 14 seconds between terminals 1 and 2.
- Check the continuity between terminals 1 and 4 after connecting the negative (–) lead from the battery to terminal 6. After disconnecting the connection between terminal 6 and the battery, check that there is continuity for 2 – 4 seconds between terminals 1 and 4, and continuity immediately for 6 – 14 seconds between terminals 1 and 2.

If operation is not as specified, replace the relay.




## Light Retractor Motor

### INSPECTION OF LIGHT RETRACTOR MOTOR

#### 1. INSPECT MOTOR OPERATION


Connect the positive (+) lead from the battery to terminal 2 and connect the negative (–) lead to terminal 1. Check that the motor runs.

If there is no motor operation, replace the motor.



#### 2. INSPECT DIODE CONTINUITY OF MOTOR

- Move the headlights to any position except the uppermost or lowermost position.
- Connect the ohmmeter positive (+) lead to terminal 4 and the negative (–) lead to terminal 5.



- (d) Reverse the test leads of the ohmmeter and inspect for continuity.


If there is continuity, replace the motor assembly.

## Headlight Retainer Relay


### INSPECTION OF HEADLIGHT RETAINER RELAY

#### 1. INSPECT HEADLIGHT CIRCUIT OPERATION

Connect the positive (+) leads from the battery to terminals 4 and 7. Connect the negative (–) lead to terminal 2. Connect the 3.4W test bulb between terminal 8 and positive (+) lead from the battery.



- (a) Disconnect the positive (+) lead from the terminal 4. Check that the test bulb is lighting.




- (b) Connect the negative (–) lead to the terminal 6. Check that the test bulb does not light.

If operation is not as specified, replace the relay.

#### 2. INSPECT TAILLIGHT CIRCUIT OPERATION

Connect the positive (+) leads from the battery to terminals 4 and 7. Connect the negative (–) lead to terminal 2. Connect the 3.4W test bulb between terminal 1 and positive (+) lead from the battery.



- (b) Connect the negative (—) lead to the terminal 6.  
Check that the test bulb does not light.

If operation is not as specified, replace the relay.

## Fog Light Switch


### INSPECTION OF FOG LIGHT SWITCH

#### INSPECT SWITCH CONTINUITY

Inspect the switch continuity between terminals.

Switch position \ Terminal	1	3
	ON	OFF
ON	○—○	
OFF		

If continuity is not as specified, replace the switch.



H-3-2

## Fog Light Relay

### INSPECTION OF FOG LIGHT RELAY

#### 1. INSPECT RELAY CONTINUITY


- Check that there is continuity between terminals 1 and 3.
- Check that there is no continuity between terminals 2 and 4.

If continuity is not as specified, replace the relay.


#### 2. INSPECT RELAY OPERATION

- Apply battery voltage across terminals 2 and 4.
- Check that there is continuity between terminals 1 and 3.

If operation is not as specified, replace the relay.



BE0051




BE0050

## Light Control Rheostat (Analog Type)

### INSPECTION OF LIGHT CONTROL RHEOSTAT


#### INSPECT RHEOSTAT OPERATION





- (b) Check that there is no continuity between terminals 1 and 3 with the rheostat turned off.

If operation is not as specified, replace the rheostat.



## Light Control Rheostat (Digital Type)

### INSPECTION OF LIGHT CONTROL RHEOSTAT



#### INSPECT RHEOSTAT OPERATION

Connect the positive (+) lead from the battery to terminal 1.

1. Connect the negative (–) lead to terminal 4.

- With the brightness at minimum, check that the voltage between terminals 1 and 3 is 9V.
- Gradually turn the rheostat toward the brighter position and check that the voltage between terminals 1 and 3 decreases from 9V to 0V.
- With the brightness at minimum, check that the voltage between terminals 2 and 4 is 0V and 12V when brightness is at any other level.

If operation is not as specified, replace the rheostat.




## Turn Signal and Hazard Warning Switch

### INSPECTION OF TURN SIGNAL AND HAZARD WARNING SWITCH

#### INSPECT TURN SIGNAL AND HAZARD WARNING SWITCH CONTINUITY


Terminal (Wire color)		9 T <sub>L</sub> (G-B)	3 T <sub>B</sub> (G-W)	8 T <sub>R</sub> (G-Y)	2 B <sub>1</sub> (G-L)	7 F (G)	6 B <sub>2</sub> (G)
Switch position							
Turn Signal	L	○	○		○	○	
	N				○	○	
	R		○	○			



## REPLACEMENT OF TURN SIGNAL AND HAZARD WARNING SWITCH

### REPLACE TURN SIGNAL AND HAZARD WARNING SWITCH

- Remove the terminals from the connector. (See page BE-2)
- Remove the turn signal and hazard switch.
- Install the turn signal and hazard switch.
- Connect the terminals to the connector. (See pages BE-3 and 18)



## Turn Signal Flasher

### INSPECTION OF TURN SIGNAL FLASHER

#### INSPECT FLASHER OPERATION


- Connect the positive (+) lead from the battery to terminal 3. Connect the negative (–) lead to terminal 2.
- Connect a 55W bulb between terminals 1 and 2, and check that the bulb goes on and off.

**NOTE:** The turn signal lights should flash 75 to 95 times per minute.

If one of the front or rear turn signal lights has an open circuit, the number of flashes will be more than 120 per minute.

If one of the side turn signal lights has an open circuit, the number of flashes will increase by about 10 per minute.

If operation is not as specified, replace the flasher.



## Fade-Out Relay

### INSPECTION OF FADE-OUT RELAY

#### 1. INSPECT COURTESY SWITCH CIRCUIT OPERATION



Connect the positive (+) lead from the battery to terminal 2. Connect the negative (–) lead to terminals 1 and 6. Connect a 3.4W test bulb between terminals 2 and 4.


- Check that the bulb lights.
- Disconnect the negative (–) lead from terminal 1, and check that the bulb fades out about 8.5 seconds later.

If operation is not as specified, replace the relay.

#### 2. INSPECT OUTSIDE HANDLE SWITCH CIRCUIT OPERATION

Connect the positive (+) lead from battery to terminal 2.





## Outside Handle Switch

### INSPECTION OF OUTSIDE HANDLE SWITCH

#### INSPECT SWITCH CONTINUITY

- (a) Check that there is continuity between terminals 1 and 2 when the switch is on.
- (b) Check that there is no continuity between terminals 1 and 2 when the switch is off.

If continuity is not as specified, replace the switch.



IC-5-2

## HEADLIGHT CLEANER

### Headlight Cleaner Control Relay

#### ON-VEHICLE INSPECTION OF HEADLIGHT CLEANER CONTROL RELAY

##### INSPECT RELAY OPERATION

- Check that there is continuity between terminal 2 and body ground with the washer switch "ON".
- Check that there is battery voltage between terminal 3 and body ground with the light control switch at "TAIL" or "HEAD".
- Check that there is continuity between terminal 5 and body ground for about 0.5 seconds when the light control switch is at "TAIL" or "HEAD" and the washer switch is pushed twice in succession.

If operation is not as specified, replace the relay.



IC-2-2

## Cleaner Motor

### INSPECTION OF CLEANER MOTOR

##### INSPECT MOTOR OPERATION

- Connect the positive (+) lead from the battery to terminal 1. Connect the negative (—) lead to terminal 2.
- Check that the motor operates.



**CAUTION:** These tests must be performed quickly (within 3 — 5 seconds) to prevent the coil from burning out.

If operation is not as specified, replace the motor.

# WIPERS AND WASHERS

## Troubleshooting

Problem	Possible cause	Remedy	Page	
			Front	Rear
Wipers do not operate or return to off position	WIPER fuse blown Wiper motor faulty Wiper switch faulty Wiring or ground faulty	Replace fuse and check for short Check motor Check switch Repair as necessary	BE-4 BE-24 BE-22	BE-4 BE-23 BE-25
Wipers do not operate in INT position	Wiper relay faulty Wiper switch faulty Wiper motor faulty Wiring or ground faulty	Check relay Check switch Check motor Repair as necessary	BE-23 BE-22 BE-24	BE-25 BE-25 BE-25
Washers do not operate	Washer hose or nozzle clogged Washer motor faulty Wiper switch faulty Wiring faulty	Repair as necessary Replace motor Check switch Repair as necessary	BE-22	BE-25

BE0111  
G-52


## Front Wiper and Washer Switch

### INSPECTION OF FRONT WIPER AND WASHER SWITCH

INSPECT FRONT WIPER AND WASHER SWITCH CONTINUITY

Switch	Terminal (Wire color) Switch position	15 W (L)	19 C <sub>1</sub> (LG-R)	14 Ew (B)	16 -S (LG)	20 +S (L-R)	26 C <sub>2</sub> (LG-B)	21 +1 (L-B)	17 +B (L-W)	22 +2 (L-O)	25 VR <sub>1</sub> (Y)
Wiper	OFF			○		○					
	INT		○	○			○	○			
	LO							○	○		
	HI								○	○	
Washer	OFF										
	ON	○		○							
INT Time Control	SLOW					50 kΩ					○
	•					34.75 kΩ					○
	•					15.75 kΩ					○
	FAST					0 kΩ					○

If continuity is not as specified, replace the switch.



BE0098

## REPLACEMENT OF FRONT WIPER AND WASHER SWITCH

### REPLACE WIPER AND WASHER SWITCH


- Remove the terminals from the connector.  
(See page BE-2)
- Remove the wiper control switch and washer switch.
- Install the wiper control switch and washer switch.
- Connect the terminals to the connector.  
(See pages BE-3 and 22)

## Front Wiper and Washer Relay


### INSPECTION OF FRONT WIPER AND WASHER RELAY

#### 1. INSPECT INTERMITTENT OPERATION OF RELAY

- Connect the positive (+) lead from the battery to terminal 12. Connect the negative (-) lead to terminals 10 and 11.
- Inspect continuity between terminals 6 and 12 as follows.



BE0072




BE0073

Disconnect terminals 1, 2 and 3		Connect terminals 1, 2 and 3	
Time (seconds)	Between terminals 6 and 12	Time (seconds)	Between terminals 6 and 12
Connect terminals 10 and 11  $1.2^{+0.3}_{-0.2}$ Continuity $4.3 \pm 1$ Continuity $0.7^{+0.4}_{-0.5}$ Continuity $4.3 \pm 1$ Continuity		Connect terminals 10 and 11  $1.2^{+0.3}_{-0.2}$ Continuity $2 \pm 0.6$ Continuity $0.7^{+0.4}_{-0.5}$ Continuity $2 \pm 0.6$ Continuity	

#### 2. INSPECT WASHER CIRCUIT OF RELAY

- Connect the positive (+) lead from the battery to terminal 12. Connect the negative (-) lead to terminal 10.
- Inspect continuity between terminals 7 and 9 as follows.

Time (seconds)	Between terminals 7 and 9	Time (seconds)	Between terminals 7 and 9
----------------	---------------------------	----------------	---------------------------




## Front Wiper Motor

### INSPECTION OF FRONT WIPER MOTOR


#### 1. INSPECT THAT MOTOR OPERATES AT LOW SPEED

- Disconnect the connector from the wiper motor.
- Connect the positive (+) lead from the battery terminal 2. Connect the negative (-) lead to motor body.
- Check that the motor operates at low speed.



#### 2. INSPECT THAT MOTOR OPERATES AT HIGH SPEED


- Disconnect the connector from the wiper motor.
- Connect the positive (+) lead from the battery terminal 1. Connect the negative (-) lead to motor body.
- Check that the motor operates at high speed.




#### 3. INSPECT THAT MOTOR OPERATES, STOPPING RAISED POSITION

- Connect the positive (+) lead from the battery terminal 2. Connect the negative (-) lead to motor body.
- Operates the motor at low speed.
- Stop the motor operation to disconnect the battery terminals except at the raised position.
- Connect terminals 2 and 3.
- Connect the positive (+) lead from the battery terminal 4. Connect the negative (-) lead to terminal 7.
- Inspect that the motor stops running at raised position after the motor operate again.

If operation is not as specified, replace the motor.





S-6-28

## Rear Wiper and Washer Switch


### INSPECTION OF REAR WIPER AND WASHER SWITCH

#### INSPECT SWITCH CONTINUITY

Inspect the continuity between terminals for each switch position shown in the table below.

Terminal Switch position	5	4	3	2	6	1
Washer (INT side)	○—○		○—○		○—○	
INT	○—○		○—○			
OFF	○—○					
ON		○—○			○—○	
Washer (ON side)		○—○			○—○	○—○

If continuity is not as specified, replace the switch.



BE0694

## Rear Wiper Relay


### INSPECTION OF REAR WIPER RELAY

#### INSPECT RELAY OPERATION

Connect the positive (+) lead from the battery to terminal 1. Connect the negative (—) lead to terminal 4.

- With connect the positive (+) lead from the battery to terminal 2, check that there is no continuity between terminals 1 and 3.
- With disconnect terminal 2, check that there is no continuity between terminals 1 and 3 for 9 — 15 seconds.

If operation is not as specified, replace the relay.




BE0693

## Rear Wiper Motor

### INSPECTION OF REAR WIPER MOTOR


#### 1. INSPECT THAT MOTOR OPERATES

(a) Connect the positive (+) lead from the battery to terminal 1. Connect the negative (—) lead to terminal 2. Operate the wiper motor. The motor should operate for 9 — 15 seconds.



## 2. INSPECT THAT MOTOR OPERATES, STOPPING STOP POSITION

- (a) Connect the positive (+) lead from the battery terminal 3. Connect the negative (-) lead to motor body. Operates the motor.
- (b) Stop motor operation anywhere except stop position by disconnecting terminal 3.



- (c) Connect terminals 3 and 4.
- (d) Connect the positive (+) lead from the battery terminal 1.
- (e) Check that the motor stops running at stop position after the motor operates again.


If operation is not as specified, replace the motor.

# INSTRUMENTS AND SENDER GAUGES


## Troubleshooting

Problem	Possible cause	Remedy	Page
Voltmeter does not work	Fuses blown	Replace in-line fuses and check for short	BE-4
	Faulty	Check voltmeter	BE-29
	Wiring faulty	Repair as necessary	
Tachometer does not work	GAUGE fuse blown	Replace fuse and check for short	BE-4
	Tachometer faulty	Check tachometer	BE-29
	Wiring faulty	Repair as necessary	
Fuel receiver gauge does not work	GAUGE fuse blown	Replace fuse and check for short	BE-4
	Fuel receiver gauge faulty	Check receiver gauge	BE-30
	Sender gauge faulty	Check sender gauge	BE-30
	Wiring or ground faulty	Repair as necessary	
Water temperature receiver gauge does not work	GAUGE fuse blown	Replace fuse and check for short	BE-4
	Water temperature receiver gauge faulty	Check receiver gauge	BE-31
	Water temperature sender gauge faulty	Check sender gauge	BE-31
	Wiring or ground faulty	Repair as necessary	
Oil pressure receiver gauge does not work	GAUGE fuse blown	Replace fuse and check for short	BE-4
	Oil pressure receiver gauge faulty	Check receiver gauge	BE-32
	Oil pressure sender gauge faulty	Check sender gauge	BE-32
	Wiring or ground faulty	Repair as necessary	
Brake warning light does not light	GAUGE fuse blown	Replace fuse and check for short	BE-4
	Bulb burned out	Replace bulb	
	Brake fluid level warning switch faulty	Check switch	BE-32
	Parking brake switch faulty	Check switch	BE-32
	Wiring or ground faulty	Repair as necessary	
Discharge warning light does not light	IGN fuse blown	Replace fuse and check for short	BE-4
	Bulb burned out	Replace bulb	
	Wiring faulty	Repair as necessary	

## Combination Meter and Gauge (Analog Type)



### COMBINATION METER CIRCUIT



No.	Wiring Connector Sides
A	1 Ground
	2 Parking Brake Switch Terminal 1 and Fluid Level Warning Switch Terminal 1
	3 Door Courtesy Switch
	4 DOME Fuse
	5 GAUGE Fuse
	6 Fuel Level Warning Switch Terminal 1
	7 IGN Fuse
	8 CHARGE Fuse
B	2 TAIL Fuse
	3 Fuel Sender Gauge Terminal 2
	4 Ground
	5 DOME Fuse
	6 CIG Fuse
	7 Light Control Rheostat Terminal 2
	8 Ignition Coil
C	1 Turn Signal Switch Terminal 9
	2 Turn Signal Switch Terminal 8
	3 Dimmer Switch Terminal 5
	4 Ground
	5 OD Relay
	6 Ground
	7 ECU and Cruise Control Computer Terminal 6
	8 Water Temperature Sender Gauge

## Speedometer

### ON-VEHICLE INSPECTION OF SPEEDOMETER

- (a) Using a speedometer tester, inspect the speedometer for allowable indicating error and check the operation of the odometer.

NOTE: Tire wear and tire over or under inflation will increase the indicating error.

- (b) Check the speedometer for pointer vibration and abnormal noises.

NOTE: Pointer vibration can be caused by a loose speedometer cable.

Standard indication (km/h)	Allowable range (km/h)
20	18 – 23
40	20 – 44
60	60 – 64.5
80	80 – 85
100	100 – 105
120	120 – 125.5
140	140 – 146
160	160 – 167

Standard indication (mph)	Allowable range (mph)
20	20 – 23
40	40 – 43.5
60	60 – 64
80	80 – 84.5
100	100 – 105
120	120 – 125.5

## Tachometer

### ON-VEHICLE INSPECTION OF TACHOMETER

- (a) Connect a tune-up test tachometer and start the engine.
- (b) Compare the tester and tachometer indications.

If the error is excessive, replace the tachometer.

#### CAUTION:

- Reversing the connection of the tachometer will damage the transistors and diodes inside.
- When removing or installing the tachometer, be careful not to drop or subject it to severe shock.


Temp. \ rpm	1000	3000	5000	7000
25°C DC13V	±100	±200	±200	±300

## Fuel Gauge

### INSPECTION OF FUEL GAUGE

#### 1. INSPECT RECEIVER GAUGE OPERATION


- (a) Disconnect the connector from the fuel sender gauge. Turn the ignition switch on and check that the receiver gauge needle moves to the empty position.



- (b) Connect the 3.4W test bulb between terminal 2 and body ground. Check that the bulb lights and the receiver gauge needle operates.

**NOTE:** Because of the silicon oil in the gauge, it will take about 90 seconds for the needle to stabilize.

If indications are not as specified, remove and test the receiver gauge.




#### 2. MEASURE RECEIVER GAUGE RESISTANCE BETWEEN TERMINALS

Between terminals	Resistance ( $\Omega$ )
IG - U	Approx. 101.9
U - E	Approx. 101.3
IG - E	Approx. 203.2

If each resistance value is not as shown in the table above, replace the receiver gauge.


#### 3. MEASURE RESISTANCE OF SENDER GAUGE

- (a) Check that the resistance changes as the float is moved from the top to bottom position.
- (b) Measure the resistance between terminals 2 and 3 at each float position.



	Float position mm (in.)	Resistance ( $\Omega$ )
F	43.7 - 49.7 (1.720 - 1.957)	$3 \pm 2.1$
1/2	135.1 (5.319)	$32.5 \pm 4.8$
E	200.2 - 206.2 (7.882 - 8.118)	$110 \pm 7.7$


If each resistance value is not as shown in the table above, replace the sender gauge.



## Fuel Level Warning

### INSPECTION OF FUEL LEVEL WARNING

#### 1. INSPECT WARNING LIGHT OPERATION





## 2. INSPECT LEVEL WARNING SWITCH OPERATION

- (a) Apply battery voltage between terminals 1 and 3 through a 3.4W bulb. Check that the bulb lights.

- (b) Submerge the switch in gasoline or water. Check that the bulb goes out.

If operation is not as specified, replace the sender gauge.



## Water Temperature Gauge

### INSPECTION OF WATER TEMPERATURE GAUGE

#### 1. INSPECT RECEIVER GAUGE OPERATION

- (a) Disconnect the connector from the sender gauge. Ground the terminal through a 3.4W bulb as shown.
- (b) Turn the ignition switch on. Check that the bulb lights up and that the receiver gauge needle rises to the upper position.

If indications are not as specified, remove and test the receiver gauge.

#### 2. MEASURE RESISTANCE OF RECEIVER GAUGE



Using an ohmmeter, measure the resistance between terminals.


If each resistance value is not as shown in the table below, replace the receiver gauge.

Between terminals	Resistance ( $\Omega$ )
IG – U	Approx. 56
U – E	Approx. 201.8
IG – E	Approx. 145.8

#### 3. MEASURE RESISTANCE OF SENDER GAUGE

Using an ohmmeter, measure the resistance between the terminal and ground.





## Oil Pressure Gauge

### INSPECTION OF OIL PRESSURE GAUGE

#### 1. INSPECT RECEIVER GAUGE OPERATION



- Disconnect the connector from the sender gauge. Ground the terminal through a 3.4W bulb as shown.
- Turn the ignition switch on. Check that the bulb starts flashing and the gauge pointer deflects.

If indications are not as specified, remove and test the receiver gauge.

#### 2. INSPECT SENDER GAUGE OPERATION

- Disconnect the connector from the sender gauge.
- Connect a 12V battery to the sender gauge terminal in series with a 3.4W bulb. Check that the bulb does not light when the engine is stopped, and flashes when the engine is running. The number of flashes should vary with engine speed.

If operation is not as specified, replace the sender gauge.



## Brake Warning

### INSPECTION OF BRAKE WARNING

#### 1. INSPECT WARNING LIGHT OPERATION


- Disconnect the connector from the brake fluid level warning switch. Connect the switch terminal 1 to body ground.
- Turn the ignition switch on. Check that the brake warning light lights.

If operation is not correct, remove and test the bulb.

#### 2. INSPECT OPERATION OF BRAKE FLUID LEVEL WARNING SWITCH

Inspect the switch operation when the switch is OFF (float up) and when the switch is ON (float down).


If operation is not as specified, replace the switch.







#### 3. INSPECT OPERATION OF PARKING BRAKE SWITCH

Using an ohmmeter, inspect the continuity between terminals 1 and 2.


- Check that there is continuity when the switch is f



## Combination Meter and Gauge (Digital Type)



### COMBINATION METER CIRCUIT




No.	Wiring connector sides	No.	Wiring connector sides
1	Ignition Switch (+)	33	Light Control Relay (Tail)
2	Body Ground of Power Source	35	Trip Computer Terminal GND
5	Remaining Fuel Quantity Signal	36	Trip Computer Terminal F
6	Starting Signal	37	Trip Computer Terminal RST
7	TEMP Signal	38	Trip Computer Terminal TAU
8	Dim Signal	39	Trip Computer Terminal ACC
9	RPM Signal	40	Trip Computer Terminal IG
10	Signal Ground	41	Trip Computer Terminal DIM
11	Power Source of Fuel Sender Gauge	42	Trip Computer Terminal 12V
12	4-pulse Signal	43	Trip Computer Terminal 5V
17	Dim Restriction Signal	45	Trip Computer Terminal DIM (12V)
18	Door (+)	46	Trip Computer Terminal VF (12V)
19	Door (—)	47	Trip Computer Terminal CK
20	Oil Pressure Sender Gauge	48	Trip Computer Terminal SET
21	Fasten Belts Relay	49	Trip Computer Terminal FUL
22	Ignition Switch (+)	50	Trip Computer Terminal CLK
23	Battery Terminal (+)	51	Trip Computer Terminal KML
24	Changing Regulator Terminal L	52	Trip Computer Terminal ARR
25	Parking Brake Switch	53	Trip Computer Terminal JST
26	OD Switch	54	Trip Computer Terminal DIM (12V)
27	Ground	55	Trip Computer Terminal GND
28	Turn Signal Switch Terminal TR	57	Pattern Select Switch 4
29	Turn Signal Switch Terminal TL	58	Pattern Select Switch 3
30	Ground	59	Ground
31	Dimmer Switch Terminal HU	61	EFI Computer Terminal W
32	Rheostat		

## **Combination Meter (Digital Type)**

### **PRECAUTIONS**

1. When checking voltage, resistance, etc., use a high impedance type tester (It is impossible with a simple tester).
2. Do not attempt to disassemble or repair individual components.
3. Do not attempt to make checks with an external power (battery etc.) applied directly to the component.
4. When the ignition switch is turned ON, indications other than the speedometer will be slightly delayed but this is normal.
5. When the ignition switch is placed at ST, all meters will go out but this is normal.
6. Do not touch circuit components as there is danger of circuit damage due to static electricity. Never reverse battery connections as it could result in instant damage to the interior of the components.
7. Do not disconnect the battery while the engine is running as this would cause an instant reverse charge (100V) resulting in damage to the interior of the components.
8. Always disconnect the battery terminals before pulling apart connectors or terminals.
9. To prevent damage, handle meters with care.

# Troubleshooting WIRING DIAGRAM




- Dim : Dim signal
- E ① : Body ground of power source
- E ② : Signal ground
- EXP : Magnifier signal
- 4P : 4-pulse signal
- FR : Remaining fuel quantity signal
- FV : Power source of fuel sender gauge
- GND : Circuit ground
- IG ⊕ : Power source
- IG ⊖ : RPM signal
- KMSW : Conversion signal
- Si : Speed sensor signal (20-pulse)
- ST : Starting signal
- TACHO Si : Wave form rectification signal of IG ⊖
- TEMP : TEMP signal


Trouble			Refer to
Speedometer	No display at all		A
	Speedometer displays [0] while driving.		B
	Flickers or fluctuates		Check cable
	Abnormal display	Difficult to comprehend	Replace speedometer
	Lights do not dim when light and rheostat S/W turned ON.		C
	Display disappears when rheostat is turned with light S/W ON.		D
	Brightness does not change even when rheostat is turned.		E
	Abnormal speedometer signal		F
	No speed unit conversion		G
Tachometer	No display at all		H
	Zero indication even with engine running.		I
	Abnormal display	Wrong display, no display change or constant display change from correct to "0" or no display at all.	Replace tachometer
	Lights do not dim when light and rheostat S/W turned ON.		J
Fuel Gauge	No display at all		K
	Fuel scale change display (magnifier) does not illuminate.		L
	Fuel warning light does not light.		M
	Fuel warning light always lit.		N
	Abnormal display	No display segment or intermediate segment illumination. No figure or symbol indication.	Replace fuel and temp. gauges
	Defective display		O
	Lights do not dim when light and rheostat S/W turned ON.		P
Water Temp. Gauge	No display at all		K
	Top segment does not flash.		M
	Abnormal display	Both indicator segments lit. No figure or symbol indication, etc.	Replace fuel and temp. gauges
	Wrong display	Display segment does not rise. Top segment flashes always. Unstable display, etc.	Q
	Lights do not dim when light and rheostat S/W turned ON.		P

NOTE: The "sub-harness (SST)" appearing in the following pages of the Troubleshooting Section refer to SST 09082-00100, Digital Meter Check Sub-Harness.






1



In LH cowl side


2



BE0419

3


Wiring Connector of Fuel Sender Gauge



CAUTION: Never short circuit terminal FV.

BE0056


4




5

Fuel and Temp. Gauges

Tachometer




SECTION	TROUBLE	
<b>B</b>	Speedometer	Speedometer displays [0] while driving




1

Speedometer




2

Speedometer




3

Speedometer






4




Speedometer




SECTION	TROUBLE	
<b>C</b>	<b>Speedometer</b>	Lights do not dim when light and rheostat S/W turned ON






SECTION	TROUBLE	
<b>D</b>	Speedometer	Display disappears when rheostat is turned with light S/W ON



SECTION	TROUBLE	
<b>E</b>	Speedometer	Brightness does not change when rheostat is turned





SECTION	TROUBLE	
<b>F</b>	Speedometer	Abnormal speedometer signal

IG S/W ON, CRUISE CONTROL MAIN S/W ON

① With the ignition S/W at ON position, is there battery voltage on terminal 14 of connector with wiring meter connector disconnected?

No

Defective control parts for CRUISE CONTROL


Yes

Connect sub-harness (SST)


② With the ignition S/W at ON position, does voltage between terminals 14 and 16 of sub-harness (SST) change from 10 to 0V when the magnet shaft is turned?

No


Replace speedometer




1





Wiring Connector



2



Sub-harness (SST)



SECTION	TROUBLE	
<b>G</b>	<b>Speedometer</b>	<b>No speed unit conversion</b>

Remove meter and connect sub-harness (SST)


① With the ignition S/W at ON position, is there speed unit conversion when rear terminals are short-circuited?

No

Replace speedometer

Yes

Replace speed scale change S/W



SECTION	TROUBLE	
<b>H</b>	Tachometer	No display at all

Only tachometer? No Refer to section A

Yes

Remove meter and connect sub-harness (SST)

① With the ignition S/W at ON position, check that voltage between terminals of tachometer connector is as follows:

Terminals 1 – 6 Battery voltage

Terminals 2 – 6 4.0 – 6.0V

Terminals 4 – 6 0 – 1.5V

No


Replace speedometer

OK

Replace tachometer

1

Tachometer



SECTION	TROUBLE	
I	Tachometer	Zero indication even with engine running

Remove meter and connect sub-harness (SST)

① With the ignition S/W at ON position, does voltage between terminals 16 and 17 of sub-harness fluctuate with variations in engine rpm?

No

Bad wiring between igniter and meter

Yes

② With the ignition S/W at ON position, does voltage between terminals 3 and 6 of tachometer connector fluctuate between 0 and 1.5V when engine speed increases from 2,000 to 3,000 rpm?


No

Replace speedometer


Yes

Replace tachometer

1




Sub-harness (SST)




2


Tachometer



SECTION	TROUBLE	
<b>J</b>	<b>Tachometer</b>	Lights do not dim when light and rheostat S/W turned ON

**NOTE:**


Connector dimming is performed by the dim signal (Dim②) of the speedometer.



SECTION	TROUBLE	
<b>K</b>	Fuel gauge Temp. gauge	No display at all


For Fuel Gauge

For Temp. Gauge




1

Fuel and Temp. Gauges



2

Fuel and Temp. Gauges



SECTION	TROUBLE	
<b>L</b>	Fuel gauge	Fuel scale change display (magnifier) does not illuminate

Remove meter and connect sub-harness (SST)

① With the ignition S/W at ON position, does magnifier illuminate when rear terminals are short-circuited?

Yes


Replace FUEL SCALE CHANGE S/W

No


Replace fuel and temp. gauges

1

Fuel and Temp. Gauges




SECTION	TROUBLE	
<b>M</b>	Fuel gauge	Warning light does not light





SECTION	TROUBLE	
<b>N</b>	Fuel gauge	Warning light always lit



M-①  
N-①




SECTION	TROUBLE	
<b>O</b>	Fuel gauge	Defective display



SECTION	TROUBLE	
<b>P</b>	Fuel gauge Water temp. gauge	Lights do not dim when light and rheostat S/W turned ON.


For Fuel Gauge

For Temp. Gauge





1

Fuel and Temp. Gauges





SECTION	TROUBLE	
<b>Q</b>	Water temp. gauge	Defective indication



## ON-VEHICLE INSPECTION OF COMBINATION METER (Digital Type)

1. REMOVE COMBINATION METER AND CONNECT SUB-HARNESS (SST)  
SST 09082-00100
2. INSPECT CIRCUIT AND PARTS OPERATION

Terminals of sub-harness	Specification	
E① — Body ground	Continuity	Zero $\Omega$
E② — Body ground		
IG⊕ — E①	Battery voltage	(Ignition switch ON)
ST — E①	8 — 11V	(Cranking)
TC — E①	Battery voltage 0 V	(Light switch and rheostat turned ON.) (Light switch turned ON and rheostat turned OFF.)
TR — E①	0 — 1.0V 0 — 1.0V 6 — 9V	(Light switch turned OFF.) (Light switch turned ON and rheostat MIN) (Light switch turned ON and rheostat MAX)
4P — E①	 4 times/revolution of magnet shaft (Ignition switch ON)	
FV — E②	4.0 — 6.0V	(Ignition switch ON)
FR — E②	4.4 — 4.8V 3.27V 2.3 — 2.7V 0.3 — 0.5V	(F level) (Ignition switch ON) (1/2 level) (Ignition switch ON) (1/4 level) (Ignition switch ON) (E level) (Ignition switch ON)
IG⊖ — E①	11 — 13V 10 — 12V	(Idling) (3,000 rpm)
TEMP — E②	1.7V	(No. 6 segment is lighted) (Ignition switch ON)



## Speedometer

### ON-VEHICLE INSPECTION OF SPEEDOMETER

- (a) Using a speedometer tester, inspect the speedometer for allowable indicating error and check operation of the odometer.

NOTE: Tire wear and tire over or under inflation will increase indication error.

- (b) Check the speedometer for pointer vibration and abnormal noises.

NOTE: Pointer vibration can be caused by a loose speedometer cable.

(km/h)

Standard indication	Allowable range
20	18 – 22
40	38 – 42
60	58 – 62
80	78 – 82
100	97 – 103
120	117 – 123

(mph)

Standard indication	Allowable range
20	19 – 21
40	39 – 41
60	59 – 61
80	78 – 82

## Tachometer

### ON-VEHICLE INSPECTION OF TACHOMETER

- (a) Connect a tune-up test tachometer and start the engine.
- (b) Compare the tester and tachometer indications.
- If the error is excessive, replace the tachometer.

#### CAUTION:

- Reversing the connection of the tachometer will damage the transistors and diodes inside.
- When removing or installing the tachometer, be careful not to drop it or subject it to heavy shocks.

(rpm)


Standard indication	Allowable range	Standard indication	Allowable range
---------------------	-----------------	---------------------	-----------------

## Fuel Gauge

### INSPECTION OF FUEL GAUGE

#### 1. INSPECT RECEIVER GAUGE OPERATION

Disconnect the connector from the fuel sender gauge.




#### 2. INSPECT POWER SOURCE LINE TO CONNECTOR

Inspect the power source line between terminal FV and body ground of the sender gauge connector.

Voltage: 4.0 – 6.0V

CAUTION: Never short circuit terminal FV.



#### 3. INSPECT OUTPUT SIGNAL VOLTAGE


Inspect the output signal voltage between terminal FR and body ground of the sender gauge connector.

Voltage: 4.4 – 4.8V at F level  
 3.27V at 1/2 level  
 2.3 – 2.7V at 1/4 level  
 0.3 – 0.5V at E level

#### 4. INSPECT SENDER GAUGE OPERATION

Inspect the resistance between terminals FR and E.


Resistance: 270 – 310  $\Omega$  212 mm (8.35 in.)  
 186 – 226  $\Omega$  162.3 – 168.3 mm  
 (6.390 – 6.626 in.)  
 140 – 180  $\Omega$  83.3 mm (3.280 in.)  
 17 – 33  $\Omega$  5.8 – 11.8 mm  
 (0.228 – 0.465 in.)




## Water Temperature Gauge


### INSPECTION OF WATER TEMPERATURE GAUGE

#### 1. INSPECT RECEIVER GAUGE OPERATION





- (d) Ground the connector of the sender gauge with the connector disconnected.
- (e) Check that the top segment flashes with the ignition switch at ON position.



## 2. INSPECT SENDER GAUGE OPERATION


Inspect the resistance between the terminals of the sender gauge and body ground.

**Resistance:** 192 — 260  $\Omega$  50°C (122°F)  
65 — 89  $\Omega$  80°C (176°F)

# REAR WINDOW DEFOGGER

## Troubleshooting

Problem	Possible cause	Remedy	Page
Rear window defogger does not work	Circuit breaker OFF	Reset breaker and check for short	BE-4
	Defogger relay faulty	Check relay	BE-61
	Defogger switch faulty	Check switch	BE-61
	Defogger wire broken	Check wires	BE-62
	Wiring and ground faulty	Repair as necessary	




## Rear Window Defogger Switch

### INSPECTION OF REAR WINDOW DEFOGGER SWITCH

#### INSPECT SWITCH OPERATION

- Connect the positive (+) lead from the battery to terminal 5. Connect the negative (–) lead to terminal 6.
- Connect an ohmmeter between terminals 2 and 6.
- Check that there is continuity between terminals 2 and 6 for 10 – 20 minutes with the switch turned on.

If operation is not as specified, replace the switch.



## Rear Window Defogger Relay

### INSPECTION OF REAR WINDOW DEFOGGER RELAY

#### 1. INSPECT RELAY CONTINUITY


- Check that there is continuity between terminal 1 and 3.
- Check that there is no continuity between terminal 2 and 4.

If continuity is not as specified, replace the relay.

#### 2. INSPECT RELAY OPERATION

Connect the positive (+) lead from the battery to terminal 1 and connect the negative (–) lead from the battery to terminal 2. Then, check that there is continuity between






## Rear Window Defogger Wires

### CAUTION:

- When cleaning the glass, use a soft, dry cloth, and wipe the glass in the direction of the wire. Take care not to damage the wires.
- Do not use detergents or glass cleaners with abrasive ingredients.
- When measuring voltage, wind a piece of tin foil around the tip of the negative probe and press the foil against the wire with your finger as shown.




## INSPECTION OF REAR WINDOW DEFOGGER WIRES

### 1. INSPECT FOR WIRE BREAKAGE

- Turn the defogger switch to ON.
- Inspect the voltage at the center of each heat wire.

Voltage	Criteria
Approx. 5V	Okay (No break in wire)
Approx. 10V or 0V	Broken wire


**NOTE:** If there is 10V, the wire is broken between the center of the wire and positive (+) end. If there is no voltage, the wire is broken between the center of the wire and ground.



### 2. INSPECT FOR WIRE BREAKAGE POINT

- Place the voltmeter positive (+) lead against the defogger positive (+) terminal.
- Place the voltmeter negative (-) lead with the foil strip against the heat wire at the positive (+) terminal end and shift it toward the negative (-) terminal end.
- The point where the voltmeter deflects from zero to several volts is the place where the heat wire is broken.

**NOTE:** If the heat wire is not broken, the voltmeter will indicate 0V at the positive (+) end of the heat wire and gradually increase to about 12V as the meter probe is moved to the other end.



## REPAIR OF REAR WINDOW DEFOGGER WIRES

- CLEAN BROKEN WIRE TIPS WITH WHITE GASOLINE
- PLACE MASKING TAPE ALONG BOTH SIDES OF WIRE TO BE REPAIRED


- Thoroughly mix the repair agent (Dupont paste M



# HEATER

## Troubleshooting

Problem	Possible cause	Remedy	Page
Blower does not work when fan switch is on	Circuit breaker OFF Heater main relay faulty Heater blower switch faulty Heater blower resistor faulty Heater blower motor faulty Wiring or ground faulty	Reset breaker and check for short Check relay Check switch Check resistor Replace motor Repair as necessary	BE-4 BE-63 BE-63 BE-64
Incorrect temperature output	Control cables broken or binding Heater hoses leaking or clogged Water valve faulty Air dampers broken Air ducts clogged Heater radiator leaking or clogged Heater control unit faulty	Check cables Replace hose Replace valve Repair dampers Repair ducts Replace radiator Repair control unit	BE-64



Q-10-2

## Heater Blower Switch

### INSPECTION OF HEATER BLOWER SWITCH

#### INSPECT SWITCH CONTINUITY

Inspect heater blower switch continuity.

Terminal Switch position	10	4	9	5	8	6	7
OFF						○	○
I	○	○				○	○
II	○	○	○			○	○
III	○	○	○	○		○	○
IV	○	○	○	○	○	○	○

\* For illumination light


If continuity is not as specified, replace the switch.


## Heater Relay

### INSPECTION OF HEATER MAIN RELAY

#### 1. INSPECT RELAY CONTINUITY

- Check that there is continuity between terminals 1 and 3.






## 2. INSPECT RELAY OPERATION

- Apply battery voltage across terminals 1 and 3.
- Check that there is continuity between terminals 2 and 5.
- Check that there is no continuity between terminals 2 and 4.

If operation is not as specified, replace the relay.




## Heater Blower Resistor

### INSPECTION OF HEATER BLOWER RESISTOR

#### INSPECT RESISTOR CONTINUITY

Check that there is continuity between terminals 1 and 6.

If there is no continuity, replace the resistor.




## Heater Control

### ADJUSTMENT OF HEATER CONTROL


#### SET AIR INLET DAMPER

Set the air inlet damper and control lever to "FRESH".




#### SET MODE SELECTOR DAMPER

Set the mode selector damper and control lever to "VEHICLE".



#### SET BALANCE DAMPER

Set the balance damper and control lever to the "BALANCE" position.



G-32

## POWER WINDOW

### Power Window Lock Switch

#### INSPECTION OF POWER WINDOW LOCK SWITCH

##### INSPECT SWITCH CONTINUITY

Inspect the switch continuity between terminals.

Terminal Switch position	1	2	3
LOCK			
OFF			
UNLOCK			

If continuity is not as specified, replace the switch.

### Power Window Master Switch

#### INSPECTION OF POWER WINDOW MASTER SWITCH

##### INSPECT SWITCH CONTINUITY

Switch	Left				Right		
Terminal	2	3	7	6	2	1	5
Switch position							
UP							
OFF							
DOWN							


If continuity is not as specified, replace the switch.


### Power Window Door Switch

#### INSPECTION OF POWER WINDOW DOOR SWITCH

##### INSPECT SWITCH CONTINUITY

Terminal	2	1	5	4	3
Switch position					
UP					






## Power Main Relay

### INSPECTION OF POWER MAIN RELAY


#### 1. INSPECT RELAY CONTINUITY

Inspect that there is continuity between terminals 1 and 3.  
Inspect that there is no continuity between terminals 2 and 4.




#### 2. INSPECT RELAY OPERATION

Inspect the continuity between terminals 2 and 4 with battery voltage applied between terminals 1 and 3.  
If continuity is not as specified, replace the relay.



Within 4 to 40 seconds



Within 60 seconds

## Power Window Motor

### INSPECTION OF POWER WINDOW MOTOR


#### 1. INSPECT CIRCUIT BREAKER OPERATION

(a) With the window in the full closed position, hold the power window switch at "UP" and check that there is a circuit breaker operation noise within 4 to 40 seconds.

(b) With the window in the fully closed position, hold the switch at "DOWN" and check that the window begins to descend within 60 seconds.

#### 2. INSPECT MOTOR OPERATION

(a) Connect the positive (+) lead from the battery to terminal 1 and connect the negative (-) lead to terminal 2, and check that the motor turns clockwise.



GA-8-2-A

## DOOR LOCK CONTROL SYSTEM


### Door Lock Control Switch

#### INSPECTION OF DOOR LOCK CONTROL SWITCH

##### INSPECT SWITCH CONTINUITY

Switch position \ Terminal	8	6	4
LOCK			
OFF			
UNLOCK			

If continuity is not as specified, replace the switch.



BE0433

### Key Unlock Switch

#### INSPECTION OF KEY UNLOCK SWITCH

##### INSPECT SWITCH OPERATION

- Check that there is continuity between terminals when the switch pin is pushed.
- Check that there is no continuity between terminals when the switch is free.

If operation is not as specified, replace the switch.

### Door Lock Relay

#### INSPECTION OF DOOR LOCK RELAY


##### 1. INSPECT RELAY CONTINUITY

- Check that there is continuity between terminals 2, 3 and 4.
- Check that there is no continuity between terminals 1, 2 and 6.

If continuity is not as specified, replace the relay.


##### 2. INSPECT RELAY OPERATION


- Connect the positive (+) lead from the battery to terminal 2. Connect the negative (-) lead to terminals 3 and 4.



BE0089

Continuity





## Door Lock Control Relay

### INSPECTION OF DOOR LOCK CONTROL RELAY

#### INSPECT DOOR LOCK CONTROL RELAY CIRCUIT

Disconnect the relay and inspect the connector on the harness side as shown in the chart below.

Terminal	Check Item	Tester Connection	Condition	Voltage or Continuity
2	Voltage	2-Body ground	—	Battery voltage
3	Continuity	3-4	—	Continuity
6	Continuity	6-Body ground	Turn door lock control switch to LOCK.	Continuity
			Turn door lock control switch to UNLOCK or OFF.	No continuity
7	Continuity	7-Body ground	Turn LH key unlock switch on.	Continuity
			Turn LH key unlock switch off.	No continuity
9	Continuity	9-Body ground	LH door lock knob pushed.	No continuity
			LH door lock knob pulled.	Continuity
10	Continuity	10-Body ground	—	Continuity
11	Continuity	11-Body ground	RH door lock knob pushed.	No continuity
			RH door lock knob pulled.	Continuity
12	Continuity	12-Body ground	Turn unlock warning switch and LH door courtesy switch off.	Continuity
			Turn unlock warning switch and/or door LH door courtesy switch off.	No continuity
13	Continuity	13-Body ground	Turn RH key unlock switch on and/or door lock control switch to UNLOCK.	Continuity
			Turn RH key unlock switch off and/or door lock control switch to LOCK or OFF.	No continuity



If circuit is correct as specified, replace the relay.


## Door Lock Solenoid

### INSPECTION OF DOOR LOCK SOLENOID

#### INSPECT SOLENOID OPERATION

- Connect the positive (+) lead from the battery to terminal A-1. Connect the negative (—) lead to terminal A-3. Check that the solenoid operates in the correct direction.
- Check that there is no continuity between terminals B-1 and B-2.
- Connect the positive (+) lead from the battery to terminal 2. Connect the negative (—) lead to terminal A-3. Check that the solenoid operates in the correct direction.
- Check that there is continuity between terminals B-1 and B-2.





## SUN ROOF


### Sun Roof Switch

#### INSPECTION OF SUN ROOF SWITCH

##### INSPECT SWITCH CONTINUITY

Terminal Switch position	3	1	4	5
OPEN				
OFF				
CLOSE				

If continuity is not as specified, replace the switch.



## Sun Roof Motor

#### INSPECTION OF SUN ROOF MOTOR

##### INSPECT MOTOR OPERATION

- Connect the positive (+) lead from the battery to terminal 2 (red wire) and the negative (-) lead to terminal 1 (green wire), and check that the motor turns clockwise.
- Connect the positive (+) lead from the battery to terminal 1 (green wire) and the negative (-) lead to terminal 2 (red wire), and check that the motor turns counterclockwise.

If operation is not as specified, replace the motor.


## Power Main Relay

#### INSPECTION OF POWER MAIN RELAY



INSPECT RELAY CONTINUITY AND OPERATION  
(See Power Main Relay on page BE-66)

# CRUISE CONTROL SYSTEM

## Wiring Diagram



Parking Brake Switch    Clutch Switch    Stop Light Switch    Cruise Control Computer    Main Switch



Speed Sensor (Analog Meter)




Control Switch

Actuator


Neutral Start Switch

Speed Sensor (Digital Meter)



## Troubleshooting

Problem	Inspection Item	No.
Cruise control does not operate.	Inspection of power source circuit	A
Vehicle speed does not reduce when coast switch turned on.	Inspection of control switch and circuit.	B
Vehicle does not accelerate when accel switch turned on.		
Vehicle speed does not return to memorized speed when resume switch turned on.		
Set speed deviates on high side.	Inspection of actuator and circuit	C
Set speed deviates on low side.		
Vehicle speed does not fluctuate when set switch turned on.	Inspection of actuator and circuit Inspection of speed sensor and circuit	C H
Setting speed does not cancel when brake pedal depressed.	Inspection of stop light switch and circuit	D
Setting speed does not cancel when parking brake pulled.	Inspection of parking brake switch and circuit	E
Setting speed does not cancel when clutch pedal depressed (M/T only).	Inspection of clutch switch and circuit	F
Setting speed does not cancel when shifted to "N" range (A/T only).	Inspection of neutral start switch and circuit	G
Speed can be set below 20 km/h (12 mph).	Inspection of speed sensor and circuit	H
Cruise control will not disengage even below 20 km/h (12 mph).		

**A INSPECTION OF SOURCE CIRCUIT**

## CONTINUED FROM PREVIOUS PAGE

Yes

Is there continuity between terminal 30 and body ground with set/coast switch turned off?

Yes

Inspect control switch.

No

**INSPECT ACCEL/RESUME SWITCH OPERATION**

Is there continuity between terminal 28 and body ground when accel/resume switch turned on?

No

Inspect the control switch.

Yes

STOP LIGHT S/W**INSPECT RELEASE VALVE CIRCUIT**

Disconnect connector from computer. Is resistance value about  $68\ \Omega$  between terminal 1 and terminal 2 of computer with brake pedal returned?

No

- Open or short circuit in wire harness between terminal 4 of stop light switch and terminal 3 of actuator.
- Open circuit in wire harness between terminal 1 of actuator and terminal 2 of computer.
- Inspect stop light switch.
- Inspect actuator.

Yes

**INSPECT STOP LIGHT SWITCH OPERATION**

Is there continuity between terminals 1 and 2 with brake pedal depressed?

No

Inspect stop light switch.

Yes

COMPUTER

Disconnect computer and inspect connector on wire harness side as follows.

**INSPECT POWER SOURCE**

Is there battery voltage between terminal 7 and body ground with main switch turned on?

No

Open or short circuit in wire harness between terminal 7 of computer and terminal 3 of main switch.

Yes


**INSPECT GROUND CONNECTION**

Is there continuity between terminal 10 and

No

- Open circuit in wire harness between terminal 10 and body ground.

CONTINUED FROM PREVIOUS PAGE



## CONTINUED FROM PREVIOUS PAGE

Yes

**INSPECT CLUTCH SWITCH CIRCUIT (M/T)**

Is there continuity between terminal 11 and body ground with clutch pedal returned ?

Yes

- Short circuit in wire harness between terminal 11 of computer and terminal 3 of clutch switch.
- Inspect clutch switch.

No

**INSPECT NEUTRAL START SWITCH CIRCUIT (A/T)**

Is there battery voltage between terminal 11 and body ground when shifting except to "N" range ?

Yes

- Short circuit in wire harness between terminal 11 of computer and terminal 3 of neutral start switch.
- Inspect neutral start switch.

No

**INSPECT PARKING BRAKE SWITCH CIRCUIT**

Is there battery voltage between terminal 12 and body ground with parking brake lever returned ?

No

- Short circuit in wire harness between terminal 12 of computer and terminal 1 parking brake switch.
- Inspect parking brake switch.

Yes

**INSPECT SPEED SENSOR CIRCUIT**

Disconnect connector from combination meter. Is there continuity between terminal C-7 (analog meter) or A-12 (digital meter) of wire harness side connector and terminal 6 of computer ?

No

- Open circuit in wire harness between terminal C-7 (analog meter) or A-12 (digital meter) of combination meter and terminal 6 of computer.

Yes

Disconnect connector from combination meter. Is there continuity between terminal 6 and body ground ?

Yes

- Short circuit in wire harness between terminal 6 of computer and terminal 20 of combination meter.

No

**SPEED SENSOR****INSPECT GROUND CONNECTION**

Disconnect connector from combination meter. Is there continuity between terminal C-6 (analog meter) or A-10 (digital meter) of wire harness side connector and body ground ?

No

- Open circuit in wire harness between terminal C-6 (analog meter) or A-10 (digital meter) and body ground.
- Body ground faulty.

Yes

CONTINUED FROM PREVIOUS PAGE

ACTUATOR

Yes

**INSPECT ACTUATOR OPERATION**Is actuator operation normal ?  
(See page BE-84)

No

Replace actuator.

Yes

Replace computer.

**B INSPECTION OF CONTROL SWITCH CIRCUIT**

Turn ignition switch off.

CONTROL S/W**INSPECT SWITCH OPERATION**Is there continuity between terminal 28 and  
body ground with accel/resume switch turned  
on ?

No

Inspect control switch.

Yes

Is there continuity between terminal 28  
and body ground with accel/resume switch  
turned off ?

Yes

Inspect control switch.

COMPUTER

No

**INSPECT ACCEL/RESUME SWITCH CIRCUIT**Is there continuity between terminal 13 and body  
ground with accel/resume switch turned on ?

No

Open circuit in wire harness between  
terminal 13 of computer and terminal 28  
of control switch.ACTUATOR

Yes

**INSPECT ACTUATOR OPERATION**Is actuator operation normal ?  
(See page BE-84)

No

Replace actuator.

**C INSPECTION OF ACTUATOR CIRCUIT**

Turn ignition switch off.

**ACTUATOR****INSPECT CABLE FREEPLAY**

Is control cable freeplay less than 10 mm (0.39 in.) ?

No

Adjust control cable freeplay.

Yes

**INSPECT ACUTATOR OPERATION**

Disconnect connector from actuator.  
Inspect actuator operation. (See page BE-84)  
Is actuator operation normal ?

No

Replace actuator.

Yes

**COMPUTER****INSPECT ACTUATOR CIRCUIT**

Is resistance value between computer terminals correct ?


Between terminals 1 and 2    about 68  $\Omega$   
Between terminals 2 and 3    about 30  $\Omega$

No

Open or short circuit in wire harness between actuator and computer.

Yes

Replace computer.

**D INSPECTION OF STOP LIGHT SWITCH CIRCUIT**

**E INSPECTION OF PARKING BRAKE SWITCH**

Turn ignition switch on.

COMPUTER

**INSPECT PARKING BRAKE SWITCH CIRCUIT**

Disconnect connector from computer.  
Is there battery voltage between terminal 12 of wire harness side connector and body ground ?

No

- Open circuit in wire harness between terminal 12 of computer and terminal 1 parking brake switch.
- Inspect parking brake switch.

Yes

Replace computer.

**F INSPECTION OF CLUTCH SWITCH CIRCUIT**

Turn ignition switch on.

CLUTCH S/W

**INSPECT GROUND CONNECTION**

Is there continuity between terminal 3 and body ground ?

No

Open circuit in wire harness between terminal 3 and body ground.

Yes

COMPUTER

**INSPECT CLUTCH SWITCH CIRCUIT**

Disconnect connector from computer.  
Is there continuity between terminal 11 of wire harness side connector and body ground with clutch pedal depressed ?

No

- Open circuit in wire harness between terminal 11 of computer and terminal 2 of clutch switch.
- Inspect clutch switch.

Yes

Replace computer.

**G INSPECTION OF NEUTRAL START SWITCH CIRCUIT**

Turn ignition switch on.

NEUTRAL START S/W

**INSPECT GROUND CONNECTION**

Is there continuity between terminal 2 and body ground?

No Open circuit in wire harness between terminal 2 and body ground.

Yes

COMPUTER

**INSPECT NEUTRAL START SWITCH CIRCUIT**

Disconnect connector from computer.  
Is there continuity between terminal 11 of wire harness side connector and body ground when shifted to "N" range?

No

- Open circuit in wire harness between terminal 11 of computer and terminal 3 of neutral start switch.
- Inspect neutral start switch.

Yes

Replace computer.

**H INSPECTION OF SPEED SENSOR CIRCUIT**

Turn ignition switch on.

**SPEED SENSOR****INSPECT GROUND CONNECTION**

Disconnect connector from combination meter.  
Is there continuity between terminal C-6 (analog meter) or A-10 (digital meter) of wire harness side connector and body ground?

Yes

Short circuit in wire harness between terminal C-6 (analog meter) or A-10 (digital meter) and body ground.

No

**COMPUTER****INSPECT SPEED SENSOR CIRCUIT**

Disconnect connector from combination meter.  
Is there continuity between terminal C-7 (analog meter) or A-12 (digital meter) of wire harness side connector and terminal 6 of computer?

No

Open circuit in wire harness between terminal C-7 (analog meter) or A-12 (digital meter) of combination meter and terminal 6 of computer.

Yes

**INSPECT SPEED SENSOR OPERATION**

Is speed sensor operation normal?  
(See page BE-83)

No

Speed sensor faulty.

Yes


Replace computer.

## Cruise Control Computer Circuit

### INSPECTION OF COMPUTER CIRCUIT

Disconnect the computer and inspect the connector on the wire harness side as shown in the chart below.

Terminal	Connection or Measure Item	Check Item	Tester Connection	Condition	Voltage or Resistance Value
1	Stop Light Switch and Release Valve	Resistance	1 – 2	Brake pedal returned	About 68 $\Omega$
2	Release Valve and Control Valve	—	—	—	—
3	Control Valve	Resistance	3 – 2	—	About 30 $\Omega$
4	Control Switch (Set/Coast)	Continuity	4 – Body Ground	Turn set/coast switch on Turn set/coast switch off	Continuity No continuity
5	OD Relay	—	—	—	—
6	Speed Sensor	—	—	—	—
7	Main Switch	Voltage	7 – Body Ground	Turn ignition switch and main switch on Turn ignition switch and main switch off	Battery voltage No voltage
8	Stop Light Switch	Voltage	8 – Body Ground	Brake pedal depressed Brake pedal returned	Battery voltage No voltage
9	STOP Fuse	Voltage	9 – Body Ground	—	Battery voltage
10	Body Ground	Continuity	10 – Body Ground	—	Continuity
11	Clutch Switch Neutral Switch	Continuity	11 – Body Ground	Clutch pedal depressed or shift into "N" range Clutch pedal returned or shift into except "N" range	Continuity No continuity
12	Parking Brake Switch	Voltage	12 – Body Ground	Parking brake pulled Parking brake returned	No voltage Battery voltage
13	Control Switch (Accel/Resume)	Continuity	13 – Body Ground	Turn accel/resume switch on Turn accel/resume switch off	Continuity No continuity



F-6-1-A



## Main Switch

### INSPECTION OF MAIN SWITCH

#### INSPECT SWITCH CONTINUITY

Switch position \ Terminal	1	2	3	4	5
OFF			○	○	○
ON	○	○	○		○

If continuity is not as specified, replace the switch.

BE0111  
G-3-2

## Control Switch


### INSPECTION OF CONTROL SWITCH

#### INSPECT SWITCH CONTINUITY

Inspect the switch continuity between terminals.

Switch position \ Terminal	28 SR	30 SS	14 EW
SET/COAST		○	○
OFF			
ACCEL/RESUME	○		○

If continuity is not as specified, replace the switch.



H-3-2

## Clutch Switch

### INSPECTION OF CLUTCH SWITCH

#### INSPECT SWITCH CONTINUITY

- Check that there is continuity between terminals 2 and 3 with the clutch pedal depressed.
- Check that there is no continuity between terminals 2 and 3 with the clutch pedal returned.

If continuity is not as specified, replace the switch.

## Neutral Start Switch

(See page AT-104)

## Parking Brake Switch

(See step 3 on page BE-30)

## Speed Sensor


### INSPECTION OF SPEED SENSOR

- INSPECT SENSOR CONTINUITY (ANALOG METER)

Check that there is continuity between terminals C-6 and

Analog Meter






## Stop Light Switch

### INSPECTION OF STOP LIGHT SWITCH

#### INSPECT SWITCH CONTINUITY

Terminal Brake pedal position	1	2	3	4
Brake pedal depressed	○	○		
Brake pedal returned			○	○

If continuity is not as specified, replace the switch.



## Actuator

### INSPECTION OF ACTUATOR

#### 1. INSPECT CONTROL CABLE FREEPLAY

Inspect that the control cable freeplay is less than 10 mm (0.39 in.).


If necessary, adjust the control cable freeplay.

#### 2. INSPECT ACTUATOR RESISTANCE

Using an ohmmeter, measure the resistance value between terminals as follows.

Resistance: 1 – 2 about 30  $\Omega$   
1 – 3 about 68  $\Omega$


If the resistance value is not as specified, replace the actuator.



#### 3. INSPECT ACTUATOR OPERATION


Connect the positive (+) lead from the battery to terminal 2 and 3. Connect the negative (–) lead to terminal 1.


- Slowly apply vacuum from 0 – 300 mmHg (0 – 11.0 in.Hg, 0 – 40.0 kPa), and check that the control cable can be pulled smoothly.
- With the vacuum stabilized, check that the control cable does not return.



- Disconnect terminal 2 or 3 and check that the control cable returns to its original position and the vacuum returns to 0 mmHg (0 in.Hg, 0 kPa).

If operation is not as specified, replace the actuator.





G-7-2

## REMOTE CONTROL MIRROR

### Outer Mirror Switch

#### INSPECTION OF OUTER MIRROR SWITCH

##### INSPECT SWITCH CONTINUITY

Mirror	Left Mirror				Right Mirror				
Terminal	7	6	2	1	3	1	2	5	4
Switch position									
Up	○		○	○	○	○	○		○
Down	○		○	○	○	○		○	○
Left		○	○	○	○	○	○		
Right		○	○	○	○	○		○	

If continuity is not as specified, replace the switch.

## Remote Control Mirror

### INSPECTION OF REMOTE CONTROL MIRROR


#### 1. INSPECT LEFT MIRROR OPERATION

- Apply 12V to terminals 2 and 3 and check that the mirror operates.  
Then, reverse the polarity, and check that the mirror revolution is reversed.
- Apply 12V to terminals 3 and 4 and check that the mirror operates.  
Then, reverse the polarity, and check that the mirror revolution is reversed.

If there is no mirror operation, replace the left mirror.

#### 2. INSPECT RIGHT MIRROR OPERATION

- Apply 12V to terminals 2 and 3 and check that the mirror operates.  
Then, reverse the polarity, and check that the mirror revolution is reversed.



IU-5-1



WJ-5-1

## MIRROR HEATER

### Mirror Heater

#### INSPECTION OF MIRROR HEATER

##### MEASURE MIRROR HEATER RESISTANCE


Measure the resistance between terminals 1 and 5.

**Resistance:** 5 — 30  $\Omega$

If resistance value is not correct, replace the mirror.

**NOTE:** The resistance value is increased according to the rise of temperature.

# THEFT DETERRENT SYSTEM WIRING DIAGRAM



## Connectors

Key Unlock Switch







Door Lock Solenoid




Door Lock Switch



Theft Deterrent Horn

Headlight Control Relay  
Taillight Control RelayBack Door Courtesy  
SwitchBack Door Key  
Unlock SwitchDiode (For RH Key Unlock  
Switch and Horn)Diode (For LH Key Unlock  
Switch and Taillight  
Control Relay)


Theft Deterrent Computer



## Troubleshooting

- Check that the operation of other systems (Door Lock Control, Open Door Warning ... etc.) are normal.
- When the system is not operating, lower the door glass and confirm under what conditions it does not operate, or malfunctions.

Problem	Section
Theft deterrent system can not be set.	A
Theft deterrent system does not operate when LH door opened.	B
Theft deterrent system does not operate when RH door opened.	C
Theft deterrent system does not cancel when ignition switch turned on or ACC position.	D
Theft deterrent system does not cancel when LH door unlocked with key.	E
Theft deterrent system does not cancel when RH door unlocked with key.	F
Horn does not blow even if theft deterrent system operated.	G
Headlights and taillights do not flash even if theft deterrent system operated.	H

**A INSPECTION OF SOURCE CIRCUIT**

CONTINUED FROM PREVIOUS PAGE

**INSPECT BACK DOOR KEY UNLOCK SWITCH OPERATION**

Is there continuity between terminal 1 and body ground with back door key unlock switch turned on?

No

Inspect back door key unlock switch.

Yes

**COMPUTER**

Disconnect computer and inspect connector on wire harness side as follows.

**INSPECT POWER SOURCE**

Is there battery voltage between terminal 5 and body ground?

No

Open circuit in wire harness between fuse and terminal 5 of computer.

Yes

**INSPECT GROUND CONNECTION**

Is there continuity between terminal 10 and body ground?

No

- Open circuit in wire harness between terminal 10 of computer and body ground.
- Body ground faulty.

Yes

**INSPECT LH KEY UNLOCK SWITCH CIRCUIT**

Is there continuity between terminal 9 and body ground with LH door locked with key?

Yes

Short circuit in wire harness between terminal 9 of computer and terminal 2 of LH key unlock switch.

No

**INSPECT RH KEY UNLOCK SWITCH CIRCUIT**

Is there continuity between terminal 9 and body ground with RH door locked with key?

Yes

Short circuit in wire harness between terminal 9 of computer and terminal 2 of RH key unlock switch.

No

CONTINUED ON NEXT PAGE

CONTINUED FROM PREVIOUS PAGE

**INSPECT LH DOOR LOCK SOLENOID CIRCUIT**

Disconnect connector from computer.  
Is there continuity between terminal 1 of wire harness side connector and body ground with LH door unlocked?

No

Open circuit in wire harness between terminal 1 of computer and terminal 2 of door lock solenoid.

Yes

**INSPECT RH DOOR LOCK SOLENOID CIRCUIT**

Disconnect connector from computer.  
Is there continuity between terminal 2 of wire harness side connector and body ground with RH door unlocked?

No

Open circuit in wire harness between terminal 2 of computer and terminal 2 of door lock solenoid.

Yes

**INSPECT LH DOOR LOCK SWITCH CIRCUIT**

Close LH Door.  
Is there continuity between terminal 6 and body ground with LH door closed?

Yes

Short circuit in wire harness between terminal 6 of computer and terminal 2 of LH door lock switch.

No

**INSPECT RH DOOR LOCK SWITCH CIRCUIT**

Close RH door.  
Is there continuity between terminal 6 and body ground with RH door closed?

Yes

Short circuit in wire harness between terminal 6 of computer and terminal 2 of RH door lock switch.

No

**INSPECT HORN, TAILLIGHT AND HEADLIGHT CIRCUIT**

Is there battery voltage between terminal 12 and body ground.

No

Open circuit in wire harness between terminal 12 of computer and horn or taillight control relay or headlight control relay.

Yes

Replace computer.

**B INSPECTION OF LH DOOR UNLOCK CIRCUIT**LH DOOR LOCK S/W**INSPECT DOOR LOCK SWITCH OPERATION**

Is LH door lock switch normal ?  
(See page BE-99)

No

Replace LH door lock switch.

Yes

COMPUTER**INSPECT DOOR LOCK SWITCH CIRCUIT**

Disconnect connector from computer.  
Is there continuity between terminal 6 of  
connector side and body ground with LH  
door closed ?

Yes

Short circuit in wire harness between  
terminal 6 of computer and terminal  
1 of LH door lock switch.

No

Replace computer.

**C INSPECTION OF RH DOOR UNLOCK CIRCUIT**RH DOOR LOCK S/W**INSPECT DOOR LOCK SWITCH OPERATION**

Is RH door lock switch normal ?  
(See page BE-99)

No

Replace RH door switch.

Yes

COMPUTER**INSPECT DOOR LOCK SWITCH CIRCUIT**

Disconnect connector from computer.  
Is there continuity between terminal 6 of  
connector side and body ground with RH  
door closed ?

Yes

Short circuit in wire harness between  
terminal 6 of computer and terminal  
1 of RH door lock switch.

No

Replace computer.

**D INSPECTION OF IGNITION SWITCH CIRCUIT**

Turn ignition switch to ON or ACC position.

Is CIG fuse normal?

No

Replace fuse.  
Is operation normal?

No

Short circuit in wire harness  
between fuse and terminal  
of computer.

Yes

Fuse faulty.

Yes

**COMPUTER****INSPECT IGNITION SWITCH CIRCUIT**

Disconnect connector from computer.  
Is there battery voltage between terminal 4 of  
wire harness side connector and body  
ground?

No

Open circuit in wire harness between fus  
and terminal 4 of computer.

Yes

Replace computer.

**E INSPECTION OF LH KEY UNLOCK SWITCH CIRCUIT**

Turn ignition switch off.

DIODE**INSPECT DIODE CONTINUITY**Is diode of key unlock switch normal ?  
(See page BE-67)

No

Replace diode.

Yes

COMPUTER**INSPECT KEY UNLOCK SWITCH CIRCUIT**Is there continuity between terminal 9 and  
body ground with LH door opened with key ?

No

Open circuit in wire harness between  
terminal 9 of computer and terminal  
1 of LH key unlock switch side diode.

Yes

Replace computer.

**F INSPECTION OF RH KEY UNLOCK SWITCH CIRCUIT**

Turn ignition switch off.

DIODE**INSPECT DIODE CONTINUITY**Is diode of key unlock switch normal ?  
(See page BE-67)

No

Replace diode.

Yes




COMPUTER**INSPECT KEY UNLOCK SWITCH CIRCUIT**Is there continuity between terminal 9 and  
body ground with RH door opened with  
key ?

No

Open circuit in wire harness between  
terminal 9 of computer and terminal  
1 of RH key unlock switch side diode.

Yes

Replace computer.

**G INSPECTION OF THEFT DETERRENT HORN CIRCUIT****THEFT DETERRENT HORN****COMPUTER**

**H INSPECTION OF LIGHT CONTROL RELAY CIRCUIT**

Turn ignition switch off.

**DIODE****INSPECT DIODE CONTINUITY**

Is diode of headlight control relay side and/or taillight control relay side normal ?  
(See page BE-14)

No

Replace diode.

Yes

**COMPUTER**

Disconnect computer and inspect connector on wire harness side as follows.

**INSPECT HEADLIGHT CONTROL RELAY CIRCUIT**

Disconnect taillight control relay and theft deterrent horn.  
Is there battery voltage between terminal 12 and body ground?

No

Open or short circuit in wire harness between terminal 12 of computer and terminal 1 of headlight control relay.

Yes

**INSPECT TAILLIGHT CONTROL RELAY CIRCUIT**


Disconnect headlight control relay and theft deterrent horn.  
Is there battery voltage between terminal 12 and body ground?

No

Open or short circuit in wire harness between terminal 12 of computer and terminal 1 of taillight control relay.

Yes

Replace computer.



## Theft Deterrent Computer

### INSPECTION OF THEFT DETERRENT COMPUTER

#### INSPECT THEFT DETERRENT COMPUTER CIRCUIT

Disconnect the computer and inspect the connector on the wire harness side as shown in the chart below.

Terminal	Check Item	Tester Connection	Condition	Voltage or Continuity
1	Continuity	1–Body Ground	F <sub>L</sub> door lock knob unlocked	Continuity
			F <sub>L</sub> door lock knob locked	No continuity
2	Continuity	2–Body Ground	F <sub>R</sub> door lock knob unlocked	Continuity
			F <sub>R</sub> door lock knob locked	No continuity
4	Voltage	4–Body Ground	Turn ignition switch to ON or ACC	Battery voltage
			Turn ignition switch off	No voltage
5	Voltage	5–Body Ground	—	Battery voltage
6	Continuity	6–Body Ground	F <sub>L</sub> or F <sub>R</sub> door opened	Continuity
			F <sub>L</sub> and F <sub>R</sub> door closed	No continuity
8	Continuity	8–Body Ground	Back door opened	Continuity
			Back door closed	No continuity
9	Continuity	9–Body Ground	F <sub>L</sub> or F <sub>R</sub> door unlocked with key	Continuity
			F <sub>L</sub> and F <sub>R</sub> door locked with key	No continuity
10	Continuity	10–Body Ground	—	Continuity
11	Continuity	11–Body Ground	Back door unlocked with key	Continuity
			Back door locked	No continuity
12	Voltage	12–Body Ground	—	Battery voltage

If circuit is correct, replace the theft deterrent computer.



IV-2-1-A

## Door Lock Switch

### INSPECTION OF DOOR LOCK SWITCH

#### INSPECT SWITCH OPERATION

- Check that there is continuity between terminals with the door closed.
- Check that there is no continuity between terminals with the door opened.

If operation is not as specified, replace the switch.


## Back Door Courtesy Switch

### INSPECTION OF BACK DOOR COURTESY SWITCH

#### INSPECT SWITCH OPERATION

- Check that there is continuity between terminal and body ground when the switch is free.
- Check that there is no continuity between terminal and body ground when the switch pin is pushed.

If operation is not as specified, replace the switch.



8E0854

## Back Door Key Unlock Switch

### INSPECTION OF BACK DOOR KEY UNLOCK SWITCH

#### INSPECT SWITCH CONTINUITY

- Check that there is continuity between terminals 1 and 3 with the switch is unlock position.
- Check that there is no continuity between terminals 1 and 3 with the switch is except unlock position.

If continuity is not as specified, replace the switch.


## Diode (For LH Key Unlock Switch and Taillight Control Relay)

### INSPECTION OF DIODE

#### INSPECT DIODE CONTINUITY

Connect the test leads of the ohmmeter to terminals 1 and 2, and check for continuity. Next reverse the test leads and check, again, for continuity.

If both of the test results are same condition, replace the diode.



H-2-2



S-3-18

## Diode (For RH Key Unlock Switch and Horn)

### INSPECTION OF DIODE

#### INSPECT DIODE CONTINUITY

- (a) Connect the test leads of the ohmmeter to terminals 1 and 2, and check for continuity. Next, reverse the test leads and check, again, for continuity.

If both of the test results are same condition, replace the diode.

- (b) Connect the test leads of the ohmmeter to terminals 2 and 3, and check for continuity. Next, reverse the test leads and check, again, for continuity.

If both of the test results are same condition, replace the diode.

## Headlight Control Relay

(See page BE-14)

## Taillight Control Relay

(See page BE-14)

## Key Unlock Switch

(See page BE-67)



BE0560

## Theft Deterrent Horn

### INSPECTION OF THEFT DETERRENT HORN

#### INSPECT HORN OPERATION

Connect the positive (+) lead from the battery to terminal 1. Connect the negative (—) lead to terminal 2. Check that the horn blows.

If operation is not as specified, replace the horn.

## Door Lock Solenoid

(See page BE-68)

# RADIO, STEREO TAPE PLAYER AND ANTENNA

## Troubleshooting

### DESCRIPTION SYMBOLS



..... Inspection



..... Check or replace part



..... Test by operating radio


### 1. DEAD RADIO AND TAPE PLAYER



- (a) No power to radio or tape player, or power but no sound.

Possible causes:

- Blown RADIO fuse
- Short circuit or broken wire in power source wire harness
- Loose connectors behind radio and tape player
- Loose speaker connector
- Defective speaker
- Broken wire in speaker wire harness
- Improperly installed radio or tape player
- Defective radio or tape player

### TEST 1




TEST 2TEST 3

- (b) Tape player okay but no sound from AM and FM or either one.


Possible causes:

- Antenna disconnected
- Antenna plug not properly connected
- Defective antenna
- Defective antenna booster
- Defective antenna cable
- Defective radio or tape player
- Blown HAZ-HORN fuse
- Short circuit or broken wire in wire harness for back-up power source

### TEST 1




### TEST 2




NOTE: Back-up power refers to the storage voltage for preset tuning. This is applied even when the ignition switch is OFF.


### TEST 3



### TEST 4



### TEST 5




(c) No sound from one speaker.


Possible causes:

- Loose speaker connector
- Broken wire in speaker wire harness
- Defective speaker
- Defective radio and tape player

### TEST 1



### TEST 2





## 2. FAINT RECEPTION

Possible causes:

- Incorrectly adjusted antenna trimmer
- Defective antenna, cable or booster
- Defective speaker
- Defective radio

### TEST



(Ex. Electronic search type)

NOTE: Adjustment of antenna trimmer.

- (1) Fully lengthen the antenna.
- (2) With the volume and tone at maximum, turn the dial to around 1,400 kHz where there is no reception.
- (3) Adjust the trimmer to where static is loudest.


### 3. BAD SOUND QUALITY

(a) Sound quality bad when radio played.


Possible causes:

- Multipath interference of excessive interception
- Tuner dial not synchronized with station
- Defective antenna, cable or booster
- Speaker improperly installed
- Vibration sound from components near speaker
- Defective speaker
- Defective radio

#### TEST 1



#### TEST 2




NOTE: FM distortion tends to increase sharply if the tuner is not synchronized.

(b) Sound quality bad when tape player played.



Possible causes:

- Bad tape
- Dirty head
- Incorrectly installed speaker
- Vibration noise from around speaker
- Defective speaker
- Defective tape player

### TEST 1



### TEST 2



NOTE: Head cleaning procedure.


- (1) Raise the cassette door with four finger. Next, using pencil or like object, push in the guide.
- (2) Using a cleaning pen or cotton applicator soaked in alcohol, clean the head surface, pinch rollers and

**4. DEFECTIVE AUTO-SEARCH MECHANISM**

Manual search possible but automatic search mechanism does not function or does not stop at all receivable stations.

Possible causes:

- Poor search sensitivity (SENS button)
- Defective radio

**TEST****Antenna Motor Control Relay****INSPECTION OF ANTENNA MOTOR CONTROL RELAY****1. INSPECT RELAY OPERATION (ANTENNA UP)**




- Connect the voltmeter positive (+) lead to terminal 1 and the negative (–) lead to terminal 4.
- Connect the positive (+) lead from the battery to terminals 7 and 8. Connect the negative (–) lead to terminal 3.
- Check that there is battery voltage.


**2. INSPECT RELAY OPERATION (ANTENNA DOWN)**

- Connect the voltmeter positive (+) lead to terminal 4 and the negative (–) lead to terminal 1.
- Connect the positive (+) lead from the battery to terminal 7. Connect the negative (–) lead to terminal 2.
- Check that there is battery voltage.

**3. INSPECT RELAY OPERATION (ANTENNA STOP)**

- Connect the voltmeter positive (+) lead to terminal 1 and the negative (–) lead to terminal 4.
- Connect the positive (+) lead from the battery to terminals 7 and 8. Connect the negative (–) lead to





## Antenna Motor

### INSPECTION OF ANTENNA MOTOR


#### INSPECT LIMIT SWITCH OPERATION

- (a) If the motor stops with the antenna up, check that there is no continuity between terminals 6 and 10.
- (b) If the motor stops with the antenna down, check that there is no continuity between terminals 6 and 9.


# CLOCK

## Troubleshooting

### CLOCK WILL NOT OPERATE



### CLOCK LOSES OR GAINS TIME



**1. INSPECT ALLOWABLE ERROR OF CLOCK**

Type	Allowable Error (per day)
3-hand quartz	$\pm 4.0$ seconds
Digital quartz	$\pm 2.5$ seconds


**2. ADJUSTMENT OF CLOCK**

Adjustment of the quartz clock requires a precise digital counter. Adjustment must be made in a shop specified by the manufacturer.

**3. STARTING OF CLOCK**

- Connect the battery terminal.
- Check the clock to see that it is running, and then set it to the correct time.

**NOTE:** Whenever the battery terminal is disconnected, make sure to set the clock to the correct time after reconnecting it.




## **TRIP COMPUTER**

### **PRECAUTIONS**


1. Before beginning troubleshooting, check that the trip computer operation is correct.
2. First check the wiring connector lines (See page BE-112) and confirm that the input source is normal.
3. When checking voltage, resistance, etc., use a high-impedance type tester (it is impossible with a simple tester).
4. Do not attempt to disassemble or repair individual components.
5. Do not attempt to make checks with an external power (battery, etc.) applied directly to the component.
6. In the flow chart, there is a high probability that the replacement part will solve the problem, although it is not 100% guaranteed.
7. Do not touch circuit components as there is danger of circuit damage due to static electricity. Never reverse battery connections as it could result in instant damage to the interior of the components.
8. Do not disconnect the battery while the engine is running as this would cause an instant reverse charge (100V), resulting in damage to the interior of the components.
9. Always disconnect the battery terminals before pulling apart connectors or terminals.
10. To prevent damage, handle meters with care.

## WIRING DIAGRAM








## Troubleshooting

Check the following before beginning Troubleshooting.



Symptom	Possible Cause	Trouble
Function keys do not operate.	DISPLAY CLUSTER or Keyboard	A
MPG display is always zero. Trip reading does increase or "ARRIVE" mode indicate " - - - - - " always.	DISPLAY CLUSTER or Keyboard	B
MPG display is always 70 or trip reading does not change.	DISPLAY CLUSTER or Keyboard	C
Lights does not dim.	DISPLAY CLUSTER or Keyboard	D
Inaccurate clock.	DISPLAY CLUSTER	E



## INSPECTION OF WIRING CONNECTOR LINE

### 1. INSPECT GROUND CONNECTION

Inspect the ground connection between terminal E and body ground of the wiring connector.

If there is no voltage repair or replace the ECV fuse, connector and wire harness.

### 2. INSPECT POWER SOURCE LINE TO CONNECTOR

(a) Inspect the battery voltage between terminals +B and GND of the wiring connector.

If there is no voltage, repair or replace the ECV fuse, connector and wire harness.

(b) Inspect the battery voltage between terminals DIM and GND of the wiring connector with the light switch turned ON.

NOTE: The voltage is nearly equal to battery voltage.


(c) Inspect the battery voltage between terminals ACC and GND of the wiring connector with the ignition switch at ACC or ON position.

NOTE: The voltage is nearly equal to battery voltage.

(d) Inspect the battery voltage between terminals VEFI and GND of the wiring connector with the ignition switch at ON position.


NOTE: The voltage is nearly equal to battery voltage.

7-terminal Connector (of Wiring)



- (e) Inspect the battery voltage between terminal *r* and body ground of wiring connector with the ignition switch at ON position.

7-terminal Connector (of Wiring)



### 3. INSPECT SPEED SENSOR LINE TO CONNECTOR

With the ignition switch at ON position, check that there is continuity between terminals *f* and GND of wiring connector four times per each revolution of the magnet shaft.

TEST	TROUBLE
<b>A</b>	Function keys do not operate.

Disconnect 8-terminal connector.

Is there continuity between the following terminals of 8-terminal connector when the key is pushed?



Key	Terminal	Key	Terminal
DATA	DATA – GND	MGP	MGP – GND
FUEL	FUEL – GND	ARRIVE	ARR – GND
CLOCK	CLK – GND	SET	SET – GND

OK



Replace DISPLAY CLUSTER  
or COMPUTER.

No


Replace Keyboard.



TEST	TROUBLE
<b>B</b>	MPG indication always Zero. Trip reading increases or "ARRIVE" mode indicates " ....." always.




TEST	TROUBLE
<b>C</b>	MPG indication always 70 miles/gal or trip reading does not change.



NOTE: If tester indication can be verified, this check is okay.

Analog Type: Needle fluctuation

Digital Type: Number change



TEST	TROUBLE
<b>D</b>	Lights do not dim.

Disconnect 14-terminal connector.


- ① With the ignition switch at ACC position and light switch turned ON, is there 0V between terminals DIM and GND of the 14-terminal connector?

No

Replace Keyboard.

Yes

Replace DISPLAY CLUSTER.



TEST	TROUBLE
<b>E</b>	Inaccurate clock.

Replace DISPLAY CLUSTER