## INTRODUCTION

## HOW TO USE THIS MANUAL

## INDEX

An INDEX is provided on the first page of each section to guide you to the item to be repaired. To assist you in finding your way through the manual, the Section Title and major heading are given at the top of every page.

## **GENERAL DESCRIPTION**

At the beginning of each section, a General Description is given that pertains to all repair operations contained in that section.

Read these precautions before starting any repair task.

## TROUBLESHOOTING

TROUBLESHOOTING tables are included for each system to help you diagnose the problem and find the cause.

## PREPARATION

Preparation lists the SST (Special Service Tools), recommended tools, equipment, lubricant and SSM (Special Service Materials) which should be prepared before beginning the operation and explains the purpose of each one.

## **REPAIR PROCEDURES**

Most repair operations begin with an overview illustration. It identifies the components and shows how the parts fit together.

Example:



IN002-09

The procedures are presented in a step–by–step format: Example:

- The illustration shows what to do and where to do it.
- The task heading tells what to do.
- The detailed text tells how to perform the task and gives other information such as specifications and warnings.



This format provides the experienced technician with a FAST TRACK to the information needed. The upper case task heading can be read at a glance when necessary, and the text below it provides detailed information. Important specifications and warnings always stand out in bold type.

## REFERENCES

References have been kept to a minimum. However, when they are required you are given the page to refer to.

## SPECIFICATIONS

Specifications are presented in bold type throughout the text where needed. You never have to leave the procedure to look up your specifications. They are also found at the end of each section, for quick reference.

## CAUTIONS, NOTICES, HINTS:

- CAUTIONS are presented in bold type, and indicate there is a possibility of injury to you or other people.
- NOTICES are also presented in bold type, and indicate the possibility of damage to the components being repaired.
- HINTS are separated from the text but do not appear in bold. They provide additional information to help you perform the repair efficiently.

## **SI UNIT**

The UNITS given in this manual are primarily expressed according to the SI UNIT(Internationai System of Unit), and alternately expressed in the metric system and in the English System. Example:

Torque: 30 N-m (310 kgf-cm, 22 ft-lbf)



## IDENTIFICATION INFORMATION VEHICLE IDENTIFICATION NUMBER

The vehicle identification number is stamped on the vehicle identification number plate and certification label.

A. Vehicle Identification Number Plate

**B.** Certification Label





## **ENGINE SERIAL NUMBER**

INQCA --01

The engine serial number is stamped on the engine block as shown.



## **GENERAL REPAIR INSTRUCTIONS**

- 1. Use fender, seat and floor covers to keep the vehicle clean and prevent damage.
- 2. During disassembly, keep parts in the appropriate order to facilitate reassembly.
- 3. Observe the following:
  - (a) Before performing electrical work, disconnect. the negative cable from the battery terminal.
  - (b) If it is necessary to disconnect the battery for inspection or repair, always disconnect the cable from the negative (–) terminal which is grounded to the vehicle body.
  - (c) To prevent damage to the battery terminal post, loosen the terminal nut and raise the cable straight up without twisting or prying it.
  - (d) Cleah the battery terminal posts and cable terminals with a clean shop rag. Do not scrape them with a file or other abrasive objects.
  - (e) Install the cable terminal to the battery post with the nut loose, and tighten the nut after installa– tion. Do not use a hammer to tap the terminal onto the post.
  - (f) Be sure the cover for the positive (+) terminal is properly in place.
- 4. Check hose and wiring connectors to make sure that they are secure and correct.
- 5. Non-reusable parts
  - (a) Always replace cotter pins, gaskets, 0– rings and oil seals etc. with new ones.
  - (b) Non–reusable parts are indicated in the com– ponent illustrations by the"♦" symbol.



### 6. Precoated parts

Precoated parts are bolts and nuts, etc. that are coated with a seal lock adhesive at the factory.

(a) If a precoated part is retightened, loosened or caused to move in any way, it must be recoated with the specified adhesive.

- (b) When reusing precoated parts, clean off the old adhesive and dry with compressed air. Then apply the specified seal lock adhesive to the bolt, nut or threads.
- (c) Precoated parts are indicated in the component illustrations by the "\*" symbol.
- 7. When necessary, use a sealer on gaskets to prevent leaks.
- 8. Carefully observe all specifications for bolt tightening torques. Always use a torque wrench.
- 9. Use of special service tools (SST) and special service materials (SSM) may be required, depending on the nature of the repair. Be sure to use SST and SSM where specified and follow the proper work procedure. A list of SST and SSM can be found in the preparation part at the front of each section in this manual.
- Medium Current Fuse and High Current Fuse Equal Amperage Rating BE1367
- 10. When replacing fuses, be sure the new fuse has the correct amperage rating. DO NOT exceed the rating or use one with a lower rating.

Illustration	Symbol	Part Name	Abbreviation
6700 BE5594		FUSE	FUSE
BE5595		MEDIUM CURRENT FUSE	M-FUSE
BE5596		HIGH CURRENT FUSE	H-FUSE
<b>BE5597</b>		FUSIBLE L!1VK	FL
BE5598		CIRCUIT BREAKER	СВ



IN-6

- Care must be taken when jacking up and supporting the vehicle. Be sure to lift and support the vehicle at the proper locations (See page IN-9).
  - (a) If the vehicle is to be jacked up only at the front or rear end, be sure to block the wheels at the opposite end in order to ensure safety.
  - (6) After the vehicle is jacked up, be sure to support it on stands. It is extremely dangerous to do any work on a vehicle raised on a jack alone, even for a small job that can be finished quickly.
- 12. Observe the following precautions to avoid damage to the parts:
  - (a) Do not open the cover or case of the ECU, ECM, PCM or TCM unless absolutely necessary. (If the IC terminals are touched, the IC may be destroyed by static electricity.)







- (b) To disconnect vacuum hoses, pull on the end, not the middle of the hose.
- (c) To pull apart electrical connectors, pull on the connector itself, not the wires.
- (d) Be careful not to drop electrical components, such as sensors or relays. If they are dropped on a hard floor, they should be replaced and not reused.
- (e) When steam cleaning an engine, protect the distributor, air filter, and VCV from water.
- (f) Never use an impact wrench to remove or install temperature switches or temperature sensors.
- (g) When checking continuity at the wire connector, insert the tester probe carefully to prevent terminals from bending.
- (h) When using a vacuum gauge, never force the hose onto a connector that is too large. Use a step-down adapter instead. Once the hose has been stretched, it may leak.
- 13. Tag hoses before disconnecting them:
  - (a) When disconnecting vacuum hoses, use tags to identify how they should be reconnected.
  - (b) After completing a job, double check that the vacuum hoses are properly connected. A label under the hood shows the proper layout.

## PRECAUTION FOR VEHICLES EQUIPPED WITH A CATALYTIC CONVERTER

CAUTION: If large amounts of unburned gasoline flow into the converter, it may overheat and create a fire hazard. To prevent this, observe the following precautions and explain them to your customer.

#### 1. Use only unleaded gasoline.

2. Avoid prolonged idling.

Avoid running the engine at idle speed for more than 20 minutes.

- 3. Avoid spark jump test.
  - (a) Perform spark jump test only when absolutely necessary. Perform this test as rapidly as possible.
  - (b) While testing, never race the engine.

#### 4. Avoid prolonged engine compression measurement.

Engine compression tests must be done as rapidly as possible.

#### 5. Do not run engine when fuel tank is nearly empty.

This may cause the engine to misfire and create an extra load on the converter.

- 6. Avoid coasting with ignition turned off and prolonged braking.
- 7. Do not dispose of used catalyst along with parts contaminated with gasoline or oil.



# FOR VEHICLES WITH AN AUDIO SYSTEM

IN006-01

Audio System displaying the sign "ANTI –THEFT SYSTEM" shown on the left has a built–in anti–theft system which makes the audio system soundless if stolen.

If the power source for the audio system is cut even once, the anti-theft system operates so that even if the power source is reconnected, the audio system will not produce any sound unless the ID number selected by the customer is input again. Accordingly, when performing repairs on vehicles equipped with this system, before disconnecting the battery terminals or removing the audio system the customer should be asked for the ID number so that the technician can input the ID number afterwards, or else a request made to the customer to input the ID number. For the method to input the ID number or cancel the anti-theft system, refer to the Owner's Manual.

## **VEHICLE LIFT AND SUPPORT LOCATIONS**



## ABBREVIATIONS USED IN THIS MANUAL

INO1D-OC

ADD	Automatic Disconnecting Differential
ALR	Automatic Locking Retractor
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
BTDC	Before Top Dead Center
Calif.	California
СВ	Circuit Breaker
C&C	Cab and Chassis
DP	Dash Pot
DRW	Double Rear Wheel
ECU	Electronic Control Unit
ELR	Emergency Locking Retractor
ESA	Electronic Spark Advance
EX	Exhaust (Manifold, Valve)
Ex.	Except
Fed.	Vehicles Sold in USA except California
FIPG	Formed in Place Gasket
FL	Fusible Link
Fr	Front
IG	Ignition
IN	Intake (Manifold, Valve)
J/6	Junction Block
LH	Left–Hand
LSPV	Load Sensing Proportioning Valve
LSP & BV	Load Sensing Proportioning and By–Pass Valve
Max.	Maximum
Min.	Minimum
MP	Multipurpose
M/T	Manual Transmission
0/D, OD	Overdrive
OHC	Over Head Camshaft
o/s	Oversize
PCV	Positive Crankcase Ventilation
PPS	Progressive Power Steering
PS	Power Steering
RH	Right–Hand
Rr	Rear
SRW	Single Rear Wheel
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
sw	Switch

TCCS	Toyota Computer Controlled System
TDC	Top Dead Center
TEMP.	Temperature
T/M	Transmission
U/S	Undersize
VCV	Vacuum Control Valve
VSV	Vacuum Switching Valve
VTV	Vacuum Transmitting Valve
w/	With
w/o	Without
2WD	Two Wheel Drive Vehicles (4 x 2)
4WD	Four Wheel Drive Vehicles (4 x 4)

## **GLOSSARY OF SAE AND TOYOTA TERMS**

This glossary lists all SAE–J 1930 terms and abbreviations used in this manual in compliance with SAE recommendations, as well as their Toyota equivalents.

SAE ABBRE- VIATIONS	SAE TERMS	TOYOTA TERMS ( )—ABBREVIATIONS	
A/C	Air Conditioning	Air Conditioner	
ACL	Air Cleaner	Air Cleaner	
AIR	Secondary Air Injection	Air Injection (AD	
AP	Accelerator Pedal		
B+	Battery Positive Voltage	+ B, Battery Voltage	
BARO	Barometric Pressure		
CAC	Charge Air Cooler	Intercooler	
CARB	Carburetor	Carburetor	
CFI	Continuous Fuel Injection	_	
СКР	Crankshaft Position	Crank Angle	
CL	Closed Loop	Closed Loop	
CMP	Camshaft Position	Cam Angle	
СРР	Clutch Pedal Position	· · · · · · · · · · · · · · · · · ·	
СТОХ	Continuous Trap Oxidizer	_	
CT P	Closed Throttle Position		
D F!	Direct Fuel Injection (Diesel)	Direct Injection (DI)	
DI	Distributor ignition	-	
DLC1 DLC2 DLC3	Data Link Connector 1 Data Link Connector 2 Data Link Connector 3	1: Check Connector 2: Toyota Diagnosis Communication Link (TDCL) 3: OBDII Diagnostic Connector	
DTC	Diagnostic Trouble Code	Diagnostic Code	
DTM	Diagnostic Test Mode	-	
ECL	Engine Control Level	_	
ECM	Engine Control Module	Engine ECU (Electronic Control Unit)	
ECT	Engine Coolant Temperature	Coolant Temperature, Water Temperature (THW)	
EEPROM	Electrically Erasable Programmable Read Only Memory	Electrically Erasable Programmable Read Only Memory (EEPROM), Erasable Programmable Read Only Memory (EPROM)	
EFE	Early Fuel Evaporation	Cold Mixture Heater (CMH), Heat Control Valve (HCV)	
EGR	Exhaust Gas Recirculation	Exhaust Gas Recirculation (EGR)	
El	Electronic Ignition	Toyota Distributable Ignition (TDI)	
EM	Engine Modification	Engine Modification (EM)	
EPROM	Erasable Programmable Read Only Memory	Programmable Read Only Memory (PROM)	
EVAP	Evaporative Emission	Evaporative Emission Control (EVAP)	
FC	Fan Control		
FEEPROM	Flash Electrically Erasable Programmable Read Only Memory	-	
FEPROM	Flash Erasable Programmable Read Only Memory		
FF	Flexible Fuel	-	
FP	Fuel Pump	Fuel Pump	
GEN	Generator	Alternator	
GND	Ground	Ground (GND)	
H02S	Heated Oxygen Sensor	Heated Oxygen Sensor (H02S)	

IAC	Idle Air Control	Idle Speed Control (ISC)
I AT	Intake Air Temperature	Intake or Inlet Air Temperature
ICM	Ignition Control Module	
IFI	Indirect Fuel Injection	Indirect injection
IFS	Inertia Fuel–Shutoff	-
ISC	Idle Speed Control	_
ĸs	Knock Sensor	Knock Sensor
MAF	Mass Air Flow	Air Flow Meter
MAP	Manifold Absolute Pressure	Manifold Pressure Intake Vacuum
мс	Mixture Control	Electric Bleed Air Control Valve (EBCV) Mixture Control Valve (MCV) Electric Air Control Valve (EACV)
M DP	Manifold Differential Pressure	-
M Ft	Multiport Fuel Injection	Electronic Fuel Injection (EFI)
MIL	Malfunction Indicator Lamp	Check Engine Light
MST	Manifold Surface Temperature	
MVZ	Manifold Vacuum Zone	
NVRAM	Non–Volatile Random Access Memory	
02S	Oxygen Sensor	Oxygen Sensor, O <sub>2</sub> Sensor (02S)
OBD	On–Board Diagnostic	On–Board Diagnostic (OBD)
oc	Oxidation Catalytic Converter	Oxidation Catalyst Converter (OC), CCo
OP	Open Loop	Open Loop
PAIR	Pulsed Secondary Air Injection	Air Suction (AS)
PCM	Powertrain Control Module	
PNP	Park/Neutral Position	
PROM	Programmable Read Only Memory	
PSP	Power Steering Pressure	-
ΡΤΟΧ	Periodic Trap Oxidizer	Diesel Particulate Filter (DPF) Diesel Particulate Trap (DPT)
RAM	Random Access Memory	Random Access Memory (RAM)
RM	Relay Module	
ROM	Read Only Memory	Read Only Memory (ROM)
RPM	Engine Speed	Engine Speed
SC	Supercharger	Supercharger
SCB	Supercharger Bypass	
SFI	Sequential Multiport Fuel Injection	Electronic Fuel Injection (EFI), Sequential Injection
SPL	Smoke Puff Limiter	
SRI	Service Reminder Indicator	
SRT	System Readiness Test	_
ST	Scan Tool	_
ТВ	Throttle Body	Throttle Body
ТВІ	Throttle Body Fuel Injection	Single Point Injection Central Fuel Injection (Ci)
тс	Turbocharger	Turbocharger
TCC	Torque Converter Clutch	Torque Converter
TCM	Transmission Control Module	Transmission ECU (Electronic Control Unit)
TP	Throttle Position	Throttle Position
TR	Transmission Range	

---

TVV	Thermal Vacuum Valve	Bimetal Vacuum Switching Valve (BVSV) Thermostatic Vacuum Switching Valve (TVSV)		
twc	Three–Way Catalytic Converter	Three–Way Catalyst (TWC) CCRO		
TWC+OC	Three–Way + Oxidation Catalytic Converter	CC <sub>R</sub> + CCo		
VAF	Volume Air Flow	Air Flow Meter		
VR	Voltage Regulator	Voltage Regulator		
VSS	Vehicle Speed Sensor	Vehicle Speed Sensor (Read Switch Type)		
wot	Wide Open Throttle	Full Throttle		
WU –OC	Warm Up Oxidation Catalytic Converter	_		
WU–TWC	Warm Up Three–Way Catalytic Converter	Manifold Converter		
3GR	Third Gear			
4GR	Fourth Gear	-		

## STANDARD BOLT TORQUE SPECIFICATIONS

#### HOW TO DETERMINE BOLT STRENGTH

	Mark	Class		Mark	Class
Hexagon head bolt	4- 5- 6- 8- 9- 4 10- 11-	4T 5T fiT 7T 8T 9T 10T 11T	Stud bolt No mark	4T	
	No mark	4T			
Hexagon flange bolt w/ washer hexagon bolt	No mark	4T		Grooved	6Т
Hexagon head bolt	Two protruding lines	5T			
Hexagon flange bolt w/ washer hexagon bolt	Two protruding lines	6Т	Welded bolt		
Hexagon head bolt	Three protruding lines	7T			4T
Hexagon head bolt	Four protruding lines	8Т			

IN008~01

#### Specified torque Diameter Pitch Class Hexagon head bolt Hexagon flange bolt mm mm N۰m kgf ⋅cm ft-lbf N·m kgf∙cm ft•lbf 52 in. Ibf 48 in. Ibf 1.25 12.5 1.25 **T** 1.25 1.5 1.5 1,150 \_ \_ \_ 6.5 56 in. Ibf 7.5 65 in. Ibf 1.25 15.5 17.5 1.25 5T 1.25 1.5 1,050 1.5 1,400 \_\_\_ — \_\_\_\_ 69 in. Ibf 78 in. lbf 1.25 1.25 6T 1.25 1.5 1,100 1,250 1.5 1,750 \_ \_\_\_ ---10.5 1.25 1.25 7T 1.25 1,050 1,700 1.5 1,500 1.5 2,300 \_\_\_ \_ \_ 1.25 8T 1.25 1.25 1,100 1,250 1.25 9T 1.25 1,450 1.25 1,300 1.25 1 OT 1.25 1.25 1,450 1,600 1.25 11T 1.25 1.25 1,600 1,800

#### SPECIFIED TORQUE FOR STANDARD BOLTS