

System Operation Check Mode

PEDESTRIAN ALERT SYSTEM (DIAGNOSTICS)

10. System Operation Check Mode

A: OPERATION

For detailed operation procedures, refer to "PC application help for Subaru Select Monitor".

B: LIST

- 1) On «Main Menu» display, select {Each System Check}.
- 2) On «Each System Check» display, select {Approach Info UNIT}.
- 3) On «Approach Info UNIT» display, select {Work Support}.
- 4) On «Work Support» display, select {System Operation Check Mode}.

Data	Customize setting	Note
Speaker Check	320 Hz	Make a single sound at a frequency of 320 Hz.
	1 kHz	Make a single sound at a frequency of 1 kHz.
	3.2 kHz	Make a single sound at a frequency of 3.2 kHz.