

## 9. Read Current Data

### A: OPERATION

For detailed operation procedures, refer to "PC application help for Subaru Select Monitor".

- 1) On «Main Menu» display, select {Each System Check}.
- 2) On «Each System Check» display, select {Approach Info UNIT}.
- 3) On «Approach Info UNIT» display, select {Current Data Display & Save}.

### B: LIST

Display	Description	Note (when normal)	Unit of measure
P-Range SW	Gear shift position	P range: when in P range Other than P range: when in other than P range	—
OIL Pressure SW	Status of oil pressure switch	Engine RUN: during engine start	—
Foot Brakes SW	Status of stop light switch	ON: when brake pedal is ON	—
Vehicle speed	Vehicle speed	Show vehicle speed	MPH
Voltage of IGN	Value of IGN power supply voltage	0 — 20.4 V	V
Speaker Terminal voltage	Value of vehicle approach information speaker voltage	0 — 4.998 V	V
P-Range SW voltage	Value of shift switch voltage	0 — 4.998 V	V
OIL Pressure SW voltage	Value of oil pressure switch voltage	0 — 4.998 V	V