

# General Description


## DRIVE SHAFT SYSTEM

### 1. General Description

#### A: SPECIFICATION

##### 1. PROPELLER SHAFT


Car line		Except for XV model	XV model	
			Gasoline engine model	HEV model
Propeller shaft type		EDJ		
Front propeller shaft joint-to-joint length: $L_1$	CVT	675.5 mm (26.59 in)		562 mm (22.13 in)
	MT	735.5 mm (28.96 in)		-
Rear propeller shaft joint-to-joint length: $L_2$		723 mm (28.46 in)		
Outer diameter of tube:	$D_1$	63.5 mm (2.50 in)		
	$D_2$	65.0 mm (2.56 in)	57.5 mm (2.26 in)	



DS-00430

## 2. FRONT AXLE SHAFT ASSEMBLY

Model	Axle shaft type	Axle diameter $\phi$ mm (in)	Axle length mm (in)
Except for XV model	AC + AAR	22 (0.87)	347.5 (13.68)
XV model	EBJ + PTJ	22 (0.87)	356.4 (14.03)



DS-00478

(A) Axle diameter

(B) Axle length

# General Description

## DRIVE SHAFT SYSTEM


### 3. REAR AXLE SHAFT ASSEMBLY

- Except for XV model

T/M type	Axle shaft type	Axle diameter $\phi$ mm (in)	Axle length mm (in)
CVT	BJ + DOJ	22 (0.87)	357.45 (14.07)
MT	EBJ + DOJ	22 (0.87)	372.5 (14.67)

- XV model

T/M type	Axle shaft type	Axle diameter $\phi$ mm (in)	Axle length mm (in)
CVT	BJ + DOJ	22 (0.87)	394.2 (15.52)
MT	EBJ + DOJ	22 (0.87)	388.5 (15.30)



DS-00409

(A) Axle diameter

(B) Axle length

## 1. PROPELLER SHAFT



- (3) Rear differential (T-type)

***T1: 31 (3.16, 22.9)***


**T2: 52 (5.30, 38.4)**

# General Description

## DRIVE SHAFT SYSTEM

### 2. FRONT AXLE

- AC + AAR type



- (1) Circlip
- (2) Baffle plate
- (3) Outer race (AAR)
- (4) Snap ring
- (5) Trunnion
- (6) Boot (AAR)
- (7) Band - drive shaft A

- (8) Band - drive shaft D
- (9) Axle shaft ASSY
- (10) Boot (AC)
- (11) Housing ASSY - front axle
- (12) Back plate - front brake
- (13) Bolt - hub
- (14) Hub unit COMPL - front axle


- (15) Nut - axle

**Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 65 (6.63, 47.9)**

**T2: 220 (22.43, 162.3)**

- EBJ + PTJ type



- (1) Circlip
- (2) Baffle plate
- (3) Outer race (PTJ)
- (4) Snap ring
- (5) Trunnion
- (6) Snap ring
- (7) Boot band

- (8) Boot (PTJ)
- (9) O-ring
- (10) EBJ shaft ASSY
- (11) Housing ASSY - front axle
- (12) Back plate - front brake
- (13) Bolt - hub

- (14) Hub unit COMPL - front axle
- (15) Nut - axle

**Tightening torque: N·m (kgf-m, ft-lb)**


**T1: 220 (22.43, 162.3)**

**T2: 65 (6.63, 47.9)**

# General Description

## DRIVE SHAFT SYSTEM

### 3. REAR AXLE



- (1) Circlip A
- (2) Baffle plate
- (3) Outer race (DOJ)
- (4) Snap ring
- (5) Ball
- (6) Cage
- (7) Circlip B
- (8) Band - drive shaft A

- (9) Inner race
- (10) Boot - drive shaft (DOJ)
- (11) Band - drive shaft B
- (12) Boot - drive shaft (BJ)  
Boot - drive shaft (EBJ)
- (13) Shaft ASSY (EBJ) (CVT model)  
Shaft ASSY (EBJ) (MT model)
- (14) Housing ASSY - rear axle
- (15) Bushing - trailing link
- (16) Back plate - rear brake

- (17) Bolt - hub
- (18) Hub unit COMPL - rear axle
- (19) Nut - axle

**Tightening torque: N·m (kgf·m, ft·lb)**

**T1: 65 (6.63, 47.9)**



**T2: 190 (19.37, 140.1)**

## C: CAUTION

- When performing any work, always wear work clothes, a work cap and protective shoes. Additionally, wear a helmet, protective goggles, etc. if necessary.
- Remove contamination including dirt and corrosion before removal, installation, disassembly or assembly.
- When performing a repair, identify the cause of trouble and avoid unnecessary removal, disassembly and replacement.
- Some vehicle components are extremely hot immediately after driving. Be wary of receiving burns from heated parts.
- Use SUBARU genuine grease, the recommended or equivalent. Do not mix grease etc. of different grades or manufacturers.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Always use the jack-up point when the shop jacks or rigid racks are used to support the vehicle.
- Apply grease onto sliding or revolving surfaces before installation.
- Be sure that the surface of brake disc, brake pad or brake shoe is free from grease or oil.
- Do not secure a part in a vise directly. Place cushioning materials such as wood blocks, aluminum plates, or waste cloth between the part and the vise.
- When the suspension-related components have been removed or replaced, perform "VDC sensor mid-point setting mode" of the VDC. <Ref. to VDC-26, VDC SENSOR MIDPOINT SETTING MODE (MODELS WITHOUT EyeSight), ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).> <Ref. to VDC-26, NEUTRAL OF STEERING ANGLE SENSOR & LATERAL G SENSOR 0 POINT SETTING (MODEL WITH EyeSight), ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).> <Ref. to VDC-27, LONGITUDINAL G SENSOR & LATERAL G SENSOR 0 POINT SETTING MODE (MODEL WITH EyeSight), ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).>

## D: PREPARATION TOOL






### 1. SPECIAL TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST20099PA010</p>	20099PA010	INSTALLER & REMOVER	<ul style="list-style-type: none"> <li>• Used for replacing the bushing - trailing link of the housing assembly - rear axle.</li> <li>• Used together with BUSHING REMOVER (20099FG000).</li> </ul>
 <p>ST20099FG000</p>	20099FG000	BUSHING REMOVER	<ul style="list-style-type: none"> <li>• Used for replacing the bushing - trailing link of the housing assembly - rear axle.</li> <li>• Used together with base part of INSTALLER &amp; REMOVER (20099PA010).</li> </ul>







# General Description

## DRIVE SHAFT SYSTEM

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST28099AC000</p>	28099AC000	BOOT BAND PLIER	Used for tightening the band - boot. (for front axle shaft)
 <p>ST-925091000</p>	925091000	BAND TIGHTENING TOOL	Used for tightening the band - boot. (A) Jig for the band (B) Ratchet wrench
 <p>ST18675AA000</p>	18675AA000	DIFFERENTIAL SIDE OIL SEAL INSTALLER	Used for installing the differential side retainer oil seal.
 <p>ST-926470000</p>	926470000	AXLE SHAFT PULLER	<ul style="list-style-type: none"> <li>Used for removing the axle shaft.</li> <li>Used together with AXLE SHAFT PULLER PLATE (28099PA110).</li> </ul>
 <p>ST28099PA110</p>	28099PA110	AXLE SHAFT PULLER PLATE	Exchange with the plate of the AXLE SHAFT PULLER (926470000) to use.

# General Description

## DRIVE SHAFT SYSTEM

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST-927080000	927080000	HUB STAND	Used for assembling the bolt - hub of the hub.
 ST28399AG000	28399AG000	HUB STAND	Used for extracting the bolt - hub.
 ST28399SA010	28399SA010	OIL SEAL PROTECTOR	<ul style="list-style-type: none"> <li>Used for installing the front axle shaft into the front differential.</li> <li>For protecting the oil seal.</li> </ul>
 ST28099PA090	28099PA090	OIL SEAL PROTECTOR	<ul style="list-style-type: none"> <li>Used for installing the rear axle shaft into the rear differential.</li> <li>For protecting the oil seal.</li> </ul>

## 2. GENERAL TOOL

TOOL NAME	REMARKS
Tie-rod ball joint puller	Used for disconnecting joints.
Dial gauge	Used for inspecting the propeller shaft run-out.
Extension cap	Used for preventing leakage of gear oil or CVTF.
Crowbar	Used for extracting the axle shaft.
Needle nose pliers	Used for tightening the band - boot of the rear axle shaft. <ul style="list-style-type: none"> <li>Snap-on 96BCP</li> <li>Or equivalent.</li> </ul>