## 7. Front Lateral Link

## A: REMOVAL

- 1) Lift up the vehicle, and then remove the rear wheels.
- 2) Remove the bolts and nuts, and then remove the trailing link.



3) Remove the lateral link assembly - front.

- (1) Remove the snap pin (a) and nut (b).
- (2) Remove the ball joint from the housing assembly rear axle.

#### Preparation tool:

#### *Tie-rod ball joint puller*

(3) Scribe alignment marks (c) on the adjusting bolt for lateral link assembly - front and on the rear sub frame assembly.

(4) Remove the adjusting bolt (d), and remove the lateral link assembly - front.

#### CAUTION:

When removing the adjusting bolt (d), make sure to fix the bolt head in place when loosening the nut (e).



### **B: INSTALLATION**

#### CAUTION:

• Be sure to use a new self-locking nut.

# • Always tighten the bushing in the state where the vehicle is at curb weight and the wheels are in full contact with the ground.

- 1) Before installation, inspect the following items and replace any faulty part with a new one.
- Visually check the lateral link assembly front for damage and deformation.
- Visually check the bushing for abnormal cracks, fatigue or damage.
- Visually check the dust cover on the ball joint for abnormal cracks, fatigue or damage.

2) Install each part in the reverse order of removal.

#### Tightening torque:

Refer to "COMPONENT" of "General Description". <Ref. to RS-3, COMPONENT, General Description.>

3) Install the rear wheels.

#### Tightening torque:

Except for C4 model: 120 N·m (12.24 kgf-m, 88.5 ft-lb) C4 model: 100 N·m (10.20 kgf-m, 73.8 ft-lb)

- 4) Inspect the wheel alignment and adjust if necessary.
- Inspection: <Ref. to FS-7, INSPECTION, Wheel Alignment.>
- Adjustment: <Ref. to FS-12, ADJUSTMENT, Wheel Alignment.>

#### CAUTION:

When the wheel alignment has been adjusted, perform the following VDC setting mode.

 Model without EyeSight: VDC sensor midpoint setting mode <Ref. to VDC-26, VDC SENSOR MID-POINT SETTING MODE (MODELS WITHOUT EyeSight), ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).>

– Model with EyeSight: Neutral of Steering Angle Sensor & Lateral G Sensor 0 point setting <Ref. to VDC-26, NEUTRAL OF STEERING ANGLE SENSOR & LATERAL G SENSOR 0 POINT SETTING (MODEL WITH EyeSight), ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDC-CM&H/U).>

– Model with EyeSight: Longitudinal G sensor & lateral G sensor 0 point setting <Ref. to VDC-27, LONGITUDINAL G SENSOR & LATERAL G SENSOR 0 POINT SETTING MODE (MODEL WITH Eye-Sight), ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).>

## C: DISASSEMBLY

Using the ST, push out the bushing B - lateral link.

#### **PREPARATION TOOL:**

#### ST-A & ST-B: INSTALLER & REMOVER (20299AE000)



## D: ASSEMBLY

1) Before assembly, inspect the following items and replace any faulty part with a new one.

- Visually check the lateral link assembly front for damage and deformation.
- Visually check the bushing for abnormal cracks, fatigue or damage.
- Visually check the dust cover on the ball joint for damage.
- 2) Using the ST, press-fit the bushing B lateral link.

#### CAUTION:

#### Make sure to press the bushing straight in.

#### Preparation tool:

#### ST-A & ST-B: INSTALLER & REMOVER (20299AE000)

