9. User Customizing

A: OPERATION

1) On «Main Menu» display, select {Each System Check}.
2) On «System Selection Menu» display, select {Integ. unit mode}.
3) On «Integ. unit mode failure diag.» display, select {Work Support}.
4) On «Work Support» display, select {Unit customizing}.
5) Change the setting with UP/DOWN key and set with the [OK] key.
List of User Customizing item

Data	Initial setting value	Customize setting	Remarks
Off delay time	30s	OFF	Room light off delay time can be selected.
		10s	
		20s	
		30s	
Auto Light Sensitivity Adjustment	Normal	Dull	Slow response
		Normal	Standard
		Sensitive	Quick response
		Very sensitive	Fairly quick response
Power rear gate setting	— (*1)	ON	Fixed at OFF because this is not applicable.
		OFF	
Lane change signal setting	ON	ON	One-touch blinker control is performed.
		OFF	One-touch blinker control is not performed.
Rear wiper auto setting	—	ON	Existence of a rear wiper linked with reverse operation can be set.
		OFF	
TPMS Setting	— (*1)	TPMS	Set to "ON" for model with TPMS.
		No TPMS	
Driver's Door Unlock Setting	Selection	Selection	The door to be unlocked when you touch the driver's door can be set.
		ALL	
Rear Gate Unlock Setting	Selection	Selection	The door to be unlocked when you touch the R gate switch can be set.
		ALL	
One-touch Turn Signal System Setup	ON	ON	ON/OFF of the one-touch blinker can be set.
		OFF	
Auto Wiper System (Rear) Setup	OFF	ON	ON/OFF of the rear wiper linked with reverse operation can be set.
		OFF	
Steering Responsive Fog Lamp Setting	OFF	ON	SRF control is performed.
		OFF	SRF control is not performed.
Rear defogger operation mode	Normal	Normal	Automatically stops in 15 minutes after the switch is turned to ON.
		Continuous	Repeats activated for 15 minutes and deactivated for 2 minutes until the switch is turned to OFF.
Security Alarm Setup	ON	ON	Security alarm (hazard, horn or siren) becomes activated.
		OFF	Security alarm becomes deactivated.
Impact Sensor Setup	OFF	ON	Workable when the Impact Sensor Setup is set to "ON". Impact sensor function becomes activated.
		OFF	Impact sensor function becomes deactivated. (Be sure to set to "OFF" for models without sensors.)
Alarm delay setup	ON		After the keyless lock operation, the alarm monitor starts after the following delay time has passed.
		ON	Delay time is 30 seconds.
		OFF	Delay time is 0 seconds.

User Customizing

Data	Initial setting value	Customize setting	Remarks
Lockout prevention	ON	ON	Key lockout prevention function is activated. (This function does not operate if safety knob is locked by hand.)
		OFF	Key lockout prevention function is deactivated.
Impact sensor (OP)	OFF	ON	Vehicle is controlled in impact sensor equipped mode. (Make sure to set to "OFF" for models without the impact sensor. When set to "ON", hazard, horn or siren become activated by keyless lock (alarm monitor start).)
		OFF	Vehicle is controlled in impact sensor non-equipped mode.
Buzzer sounding setting	ON	ON	Buzzer operates when lock/unlock is selected by keyless entry system operation.
		OFF	Buzzer does not operate when lock/unlock is selected by keyless entry system operation.
Abnormal warning lamp flashing setting	ON	ON	Hazard blinks when lock/unlock is selected by keyless entry system operation.
		OFF	Hazard is not interlocked when lock/unlock is selected by keyless entry system operation.
Passive Alarm	OFF	ON	
		OFF	
Door open warning	ON	ON	
		OFF	
Dome Light Alarm Setting	OFF	ON	Room light illuminates interlocking with alarm.
		OFF	Room light does not illuminate interlocking with alarm.
Auto A/C ECU Setting	— (*1)	ON	Diagnoses with auto A/C CM.
		OFF	Diagnoses without auto A/C CM.
wiper deicer	— (*1)	ON	Wiper deicer control is performed.
		OFF	Wiper deicer control is not performed.
Illumination Control On/Off	ON	ON	
		OFF	
Sedan/Wagon Setting	— (*1)	SEDAN	Body control is performed for Sedan.
		WAGON	Body control is performed for Wagon.
MT/AT Setting	— (*1)	MT	Body control is performed for MT.
		AT	Body control is performed for AT.
6MT Setting	— (*1)	6MT	Body control is performed for 6MT.
		Other than 6MT	Body control is performed for other than 6MT.
Illumination Sensor Setting	— (*1)	ON	Set to "ON" for model with auto light.
		OFF	
Factory initial setting	Market	Market	Customize setting is reset when mode is switched from Market to Factory.
		Factory	
Welcome Light Off Delay Time(Exiting)	30s	OFF	Length of the lighting time can be set.
		30s	
		60s	
		90s	
Welcome Light Off Delay Time(Approaching)	30s	OFF	Length of the lighting time can be set.
		30s	
		60s	
		90s	
Keyless Buzzer Volume	5	1 — 7	Buzzer volume can be set.

*1: Customization item according to the actual vehicle equipment

BC(diag)-19

6) After setting, make sure that the setting changed in the {Current Data Display & Save} is same as vehicle equipment.

CAUTION:
- **The above settings must match the actual vehicle equipment.**
- **Do not change settings except for setting above while setting the functions.**
- **Be sure not to change Factory initial setting except when installing a new body integrated unit.**

NOTE:
For detailed operation procedures, refer to "PC application help for Subaru Select Monitor".