


FUSIBLE LINKS



7.5A  
CHARGE

15A  
ENGINE

15A  
HAZ HORN

15A  
TAIL

15A  
HEAD  
(RH UPR)

15A  
HEAD  
(LH UPR)



15A  
EFI

20A  
WIPER

15A  
STOP



15A  
HEAD  
(RH LWR)

15A  
HEAD  
(LH LWR)

USE DESIGNATED FUSES ONLY

