

Read Diagnostic Trouble Code (DTC)

BODY CONTROL SYSTEM (DIAGNOSTICS)

6. Read Diagnostic Trouble Code (DTC)

A: OPERATION

For details concerning the work procedure, refer to the "PC application help for Subaru Select Monitor".

NOTE:

For details concerning DTC, refer to List of Diagnostic Trouble Code (DTC). <Ref. to BC(diag)-26, List of Diagnostic Trouble Code (DTC).>