TIRE PRESSURE MONITORING SYSTEM (DIAGNOSTICS)

## **13.List of Diagnostic Trouble Code (DTC)**

## A: LIST

DTC	Item	Contents of diagnosis	Remarks
C2021	Tire 1 Air Pressure Decrease	Tire pressure of tire 1 is reduced.	<ref. 1<br="" c2021="" dtc="" tire="" to="" tpm(diag)-26,="">AIR PRESSURE DECREASE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2022	Tire 2 Air Pressure Decrease	Tire pressure of tire 2 is reduced.	<ref. 2<br="" c2022="" dtc="" tire="" to="" tpm(diag)-26,="">AIR PRESSURE DECREASE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2023	Tire 3 Air Pressure Decrease	Tire pressure of tire 3 is reduced.	<ref. 3<br="" c2023="" dtc="" tire="" to="" tpm(diag)-26,="">AIR PRESSURE DECREASE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2024	Tire 4 Air Pressure Decrease	Tire pressure of tire 4 is reduced.	<ref. 4<br="" c2024="" dtc="" tire="" to="" tpm(diag)-27,="">AIR PRESSURE DECREASE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2121	Transmitter 1 No Data	Data cannot be received from transmitter 1.	<ref. c2121<br="" dtc="" to="" tpm(diag)-27,="">TRANSMITTER 1 NO DATA, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2122	Transmitter 2 No Data	Data cannot be received from transmitter 2.	<ref. c2122<br="" dtc="" to="" tpm(diag)-27,="">TRANSMITTER 2 NO DATA, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2123	Transmitter 3 No Data	Data cannot be received from transmitter 3.	<ref. c2123<br="" dtc="" to="" tpm(diag)-27,="">TRANSMITTER 3 NO DATA, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2124	Transmitter 4 No Data	Data cannot be received from transmitter 4.	<ref. c2124<br="" dtc="" to="" tpm(diag)-28,="">TRANSMITTER 4 NO DATA, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2221	Transmitter 1 Pressure Data Abnormal	Transmitter 1 data contents are abnormal.	<ref. c2221<br="" dtc="" to="" tpm(diag)-29,="">TRANSMITTER 1 PRESSURE DATA ABNORMAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2222	Transmitter 2 Pressure Data Abnormal	Transmitter 2 data contents are abnormal.	<ref. c2222<br="" dtc="" to="" tpm(diag)-29,="">TRANSMITTER 2 PRESSURE DATA ABNORMAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2223	Transmitter 3 Pressure Data Abnormal	Transmitter 3 data contents are abnormal.	<ref. c2223<br="" dtc="" to="" tpm(diag)-29,="">TRANSMITTER 3 PRESSURE DATA ABNORMAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2224	Transmitter 4 Pressure Data Abnormal	Transmitter 4 data contents are abnormal.	<ref. c2224<br="" dtc="" to="" tpm(diag)-30,="">TRANSMITTER 4 PRESSURE DATA ABNORMAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2321	Transmitter 1 Function Code Abnormal	Function code has error.	<ref. c2321<br="" dtc="" to="" tpm(diag)-31,="">TRANSMITTER 1 FUNCTION CODE ABNORMAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>

## List of Diagnostic Trouble Code (DTC)

TIRE PRESSURE MONITORING SYSTEM (DIAGNOSTICS)

DTC	Item	Contents of diagnosis	Remarks
C2322	Transmitter 2 Function Code Abnormal	Function code has error.	<ref. c2322<br="" dtc="" to="" tpm(diag)-31,="">TRANSMITTER 2 FUNCTION CODE ABNORMAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2323	Transmitter 3 Function Code Abnormal	Function code has error.	<ref. c2323<br="" dtc="" to="" tpm(diag)-31,="">TRANSMITTER 3 FUNCTION CODE ABNORMAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2324	Transmitter 4 Function Code Abnormal	Function code has error.	<ref. c2324<br="" dtc="" to="" tpm(diag)-32,="">TRANSMITTER 4 FUNCTION CODE ABNORMAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2421	Transmitter 1 Battery Voltage Decrease	Transmitter battery voltage is low.	<ref. c2421<br="" dtc="" to="" tpm(diag)-33,="">TRANSMITTER 1 BATTERY VOLTAGE DECREASE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2422	Transmitter 2 Battery Voltage Decrease	Transmitter battery voltage is low.	<ref. c2422<br="" dtc="" to="" tpm(diag)-33,="">TRANSMITTER 2 BATTERY VOLTAGE DECREASE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2423	Transmitter 3 Battery Voltage Decrease	Transmitter battery voltage is low.	<ref. c2423<br="" dtc="" to="" tpm(diag)-33,="">TRANSMITTER 3 BATTERY VOLTAGE DECREASE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2424	Transmitter 4 Battery Voltage Decrease	Transmitter battery voltage is low.	<ref. c2424<br="" dtc="" to="" tpm(diag)-34,="">TRANSMITTER 4 BATTERY VOLTAGE DECREASE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
C2521	Vehicle Speed Is Abnormal	Vehicle speed signal is not input to the control module when the vehi- cle speed is 6 km/h (3.7 MPH) or more.	<ref. c2521="" dtc="" to="" tpm(diag)-35,="" vehi-<br="">CLE SPEED IS ABNORMAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>