

### **14. System Operation Check Mode**

#### **A: OPERATION**

**CAUTION:**

After executing the system operation check mode, execute the Clear Memory Mode. <Ref. to EN(H4DO w/o HEV)(diag)-65, OPERATION, Clear Memory Mode.>

**NOTE:**

For detailed operation procedures, refer to “PC application help for Subaru Select Monitor”.