

### 9. Air Cleaner Element

#### A: REPLACEMENT

Refer to “IN” section for air cleaner element replacement. <Ref. to IN(H4DO(w/o HEV))-4, Air Cleaner Element.> <Ref. to IN(H4DO(HEV))-4, Air Cleaner Element.>