CONTINUOUSLY VARIABLE TRANSMISSION (DIAGNOSTICS)

8. Clear Memory Mode

A: OPERATION

For details concerning the work procedure, refer to the "PC application help for Subaru Select Monitor".

CAUTION:

• If the AT learning value is cleared, learned control memory is cleared.

• If the AT learning value is cleared, perform learning. <Ref. to CVT(w/o HEV)(diag)-25, Learning Control.>