
59. Harness Components Location

A: LOCATION

1. BODY HARNESS




- (1) Front wiring harness
- (2) Engine wiring harness
- (3) Bulkhead wiring harness
- (4) Instrument panel wiring harness
- (5) Front door cord RH
- (6) Rear door cord RH

- (7) Rear wiring harness RH
- (8) Rear wiring harness LH
- (9) Roof cord
- (10) Rear gate cord (UPR)
- (11) Rear door cord LH
- (12) Front door cord LH

- (13) Generator cord
- (14) Rear gate cord (LWR)
- (15) Active grille shutter adapter cord
- (16) Occupant detection harness

2. HYBRID HARNESS



- (17) Electric oil pump harness
- (18) Inverter harness
- (19) Inverter harness
- (20) Inverter harness
- (21) Power cable